




















































Original	Replacement	Original	Replacement
	Power		Power
	Mute		Mute
	Vol+		Vol +
	Vol-		Vol -
	Prog+		Ch +
	Prog-		Ch -
	[≡]/TXT		Text
	[+]/Display		Info
	Tv/DVB-T		Smart
	[]/Line		Media
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	-/--		Shift + Guide
	PRE		Pre Ch
	Up/P+		Up
	Down/P-		Down
	Right/Vol+		Right
	Left/Vol-		Left
	[II]/Tv Menu		Menu
	-IXI-/Exit		Exit
	Sleep/Timer		Shift + Power
	-I/I-/P.STD		Shift + Format
	-I/I-/S.STD		Shift + Dual
	[<>]/P.Size		Format
	Open/Close		Eject
	Rec		Rec





Original	Replacement	Original	Replacement
	Stop		Dual
	Play		Subt
	Pause		Options
	<</< Slow		TV/R
	Slow >/>>		Shift + Ch -
	l<</<l Step		Shift + Ch +
	Step l>/>>l		Guide
	Red/Setup		3D
	Green/Input		Back
	Yellow/Title		AV
	Blue/Menu		Ok
	PIP On/Off		
	PIP Source		
	PIP Sound		
	PIP Swap		
	Timer/repeat		
	[≡i]/A-B		

