







































































Original		Replacement		Original		Replacement	
	Power		Power		P+		CH+ / Page+
	Tv/DTV		TV/Radio /		Vol-		Vol-
	Source		AV / Input / RDS		P-		CH- / Page-
	1		1		Guide		Guide / EPG / -/--
	2		2		Menu		Menu / Home
	3		3		W.Link		Display / Media
	4		4		Tools		Setup / OPT /
	5		5		Return		Back / Return
	6		6		Up		Up
	7		7		Left		Left
	8		8		Enter		OK
	9		9		Right		Right
	-/--		Shift + Guide / EPG / -/--		Info		Info / Angle
	0		0		Down		Down
	PRE-CH		Fav / Marker / PC		Exit		Exit / Cancel / Clear
	Vol+		Vol+		Red		Red / Netflix / Search
	Mute		Mute / Dimmer		Green		Green / APP / Repeat



