







































































Original		Replacement		Original		Replacement	
	Power		Power		9		9
	Input 1		Shift + 1		[+]/Timer		Info / Angle
	Input 2		Shift + 2		[+]/Timer		Sleep / Timer
	Input 3		Shift + 3		0		0
	Input 4		Shift + 4		HDMI Control		Smart / List
	Input 5		Shift + 5		P+		CH+ / Page+
	PC		Fav / Marker / PC		I-II		Audio / Lang I/II
	[+]/[≡◇]		Setup / OPT /		Vol+		Vol+
	[< >]		Picture / Format		P-		CH- / Page-
	1		1		Mute		Mute / Dimmer
	2		2		Vol-		Vol-
	3		3		Return		Back / Return
	4		4		Up		Up
	5		5		Home Menu		Menu / Home
	6		6		Left		Left
	7		7		Enter		OK
	8		8		Right		Right



