






















































































Original	Replacement	Original	Replacement
	Power		Power
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	i		Info
	AV		AV
	Red/Zoom		Red
	Green/(↔)		Green
	Yellow/Timer		Yellow
	Blue/Picture		Blue
	O)/I/I		Dual
	Menu		Menu
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	[≡]		Text
	Back		Back
	P+		Ch +
	P-		Ch -
	Vol+		Vol +
	Vol-		Vol -
	^[+]		Format
	Play/[?]		Play
	>>/[♦]		>>













































































	Original	Replacement	Original	Replacement
	√/Timer	 Options		
	Stop/[X]	 Stop		
	Pause/[≡i]	 Pause		
	[■]	 Subt		
	[←■]	 TV/R		
	[⇕■]	 3D		
	♪	 +  Shift + Dual		























Original	Replacement	Original	Replacement
 Power	 Power	 P-	 Ch -
 Mute	 Mute	 Vol+	 Vol +
 1	 1	 Vol-	 Vol -
 2	 2	 Red/Zoom	 Red
 3	 3	 Green/(↔)	 Green
 4	 4	 Yellow/Timer	 Yellow
 5	 5	 Blue/Picture	 Blue
 6	 6		
 7	 7		
 8	 8		
 9	 9		
 0	 0		
 AV	 AV		
 i	 Info		
 O/I/II	 Dual		
 [≡]	 Text		
 P+	 Ch +		
			
			









































































Original		Replacement		Original		Replacement	
	[↕■]		3D				
	♪		Shift + Dual				
	Menu		Menu				
	Back		Back				
	OK		Ok				
	Up		Up				
	Down		Down				
	Right		Right				
	Left		Left				






















Original	Replacement	Original	Replacement
 Power	 Power	 Green/(↔)	 Green
 Mute	 Mute	 Yellow/Timer	 Yellow
 1	 1	 Blue/Picture	 Blue
 2	 2	 OK	 Ok
 3	 3	 Up	 Up
 4	 4	 Down	 Down
 5	 5	 Right	 Right
 6	 6	 Left	 Left
 7	 7	 P+	 Ch +
 8	 8	 P-	 Ch -
 9	 9	 Vol+	 Vol +
 0	 0	 Vol-	 Vol -
 i	 DISPLAY INFO	 <<	 <<
 AV	 TIMER AV	 Play/[?]	 Play
 O/I/II	 SOUND DUAL	 >>/[♦]	 >>
 Menu	 TOP MENU MENU	 Stop/[X]	 Stop
 Red/Zoom	 A	 Pause/[≡i]	 Pause





Original	Replacement	Original	Replacement
 ^/[+]	 Format		
 √/Timer	 Options		
 [■]	 Subt		
 [←■]	 TV/R		
 [↓■]	 3D		
 ♪	 +  Shift + Dual		
 Back	 Back		
 [≡]	 Text		

