







































































	Original	Replacement		Original	Replacement
	1		1		A-B
	2		2		Angle
	3		3		Repeat
	4		4		OSD
	5		5		Return
	6		6		Enter
	7		7		Vol-
	8		8		Vol+
	9		9		Mute
	0		0		Stop
	Zoom		Eject		Play
	Menu		Menu		Pause
	Audio		Dual		<<
	Subtitle		Subt		>>
	Title		Info		Left
	Mode		Pre Ch		Right
	Setup		Options		I<<
					3D
					Smart
					Text
					Media
					Back
					Ok
					Vol -
					Vol +
					Mute
					Stop
					Play
					Pause
					<<
					>>
					Left
					Right
					I<<



