












Original	Replacement
	 Smart / List
	 Text / Goto
	 Display / Media
	 Power
	 Mute / Dimmer
	 1
	 2
	 3
	 4
	 5
	 6
	 7
	 8
	 9
	 0
	 Back / Return
	 Fav / Marker / PC

Original	Replacement
	 Subtitle / EQ
	 Info / Angle
	 Picture / Format
	 Vol+
	 Shift + CH+ /
	 CH+ / Page+
	 Vol-
	 Shift + CH- /
	 CH- / Page-
	 Audio / Lang I/II
	 Shift + Audio / Lang I/II
	 Sound / Title
	 Guide / EPG / -/-
	 Up
	 Left
	 OK
	 Right





Original	Replacement
Menu	Menu / Home
Down	Down
Exit	Exit / Cancel / Clear
Red	Red / Netflix / Search
Green	Green / APP / Repeat
Yellow	Yellow / YouTube / Repeat
Blue	Blue / Prime Video / Random
Play	Play / Slow
Pause	Pause / Step / Freeze
Stop	Stop / Hold
Rec	Rec / Rec Mode
<<	<< / Tune-
>>	>> / Tune+
I<<	I<< / Preset-
>>I	>>I / Preset+
Timer	Sleep / Timer
Aspect	Zoom / Size

Original	Replacement

