







































































Original	Replacement	Original	Replacement
 Power	 Power	 Prog+	 Ch +
 1	 1	 Prog-	 Ch -
 2	 2	 Menu	 Menu
 3	 3	 List	 List
 4	 4	 Back	 Back
 5	 5	 Exit	 Exit
 6	 6	 Up	 Up
 7	 7	 Left	 Left
 8	 8	 OK	 Ok
 9	 9	 Right	 Right
 0	 0	 Down	 Down
 EPG	 Guide	 Red / Timer	 Red
 Info	 Info	 Red / Timer	 AV
 Vol+	 Vol +	 Green / FAV	 Green
 Vol-	 Vol -	 Green / FAV	 Pre Ch
 Mute	 Mute	 Yellow / Repeat	 Yellow
 TV / Radio	 TV/R	 Blue / Goto	 Blue



