







































































Original	Replacement	Original	Replacement
	Power		Power
	Mute		Mute / Dimmer
	TV / Radio		TV/Radio /
	Subtitle		Subtitle / EQ
	Text		Text / Goto
	HD / SD		Display / Media
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	Back		Back / Return
	0		0
	AV		AV / Input / RDS
	Vol+		Vol+
	Menu		Menu / Home
	Exit		Exit / Cancel / Clear
	CH+		CH+ / Page+
	Vol-		Vol-
	Up		Up
	CH-		CH- / Page-
	Left		Left
	OK		OK
	Right		Right
	Down		Down
	Home		D.Menu / Top
	EPG		Guide / EPG / -/-
	List		Smart / List
	Fav		Fav / Marker / PC
	Dual Screen		Setup / OPT /





Original	Replacement
	Info / Angle
	Red / Netflix / Search
	Stop / Hold
	Green / APP / Repeat
	Pause / Step / Freeze
	Play / Slow
	<< / Tune-
	Yellow / YouTube / Repeat
	>> / Tune+
	Blue / Prime Video / Random
	Shift + Green / APP /
	Picture / Format
	Sleep / Timer
	Audio / Lang I/II

Original	Replacement

