





































































Original	Replacement	Original	Replacement
 Standby	 Power	 Left	 Left
 Mute	 Mute	 OK	 Ok
 P/N	 Smart	 CH+	 Ch +
 Open/Close	 Eject	 CH-	 Ch -
 >>	 >>	 Vol+	 Vol +
 Play/Pause	 Play	 Vol-	 Vol -
 Stop	 Stop	 Slow	 Back
 I<<	 I<<	 Goto	 Media
 >>I	 >>I	 1	 1
 Setup	 Options	 2	 2
 Source	 AV	 3	 3
 Info	 Info	 4	 4
 Return/Exit	 Exit	 5	 5
 Up	 Up	 6	 6
 Down	 Down	 7	 7
 Right	 Right	 8	 8
		 9	 9





Original		Replacement		Original		Replacement	
	0		0				
	Program		Sleep				
	Title/TTX		Text				
	Audio		Dual				
	Subtitle		Subt				
	Red/Repeat		Red				
	Green/A-B		Green				
	Yellow/Menu		Yellow				
	Blue/Angle		Blue				
	EPG		Guide				
	Favorite		Pre Ch				
	Tv/Radio		TV/R				
	Zoom		Shift + Eject				

