







































































Original	Replacement	Original	Replacement
 Power	 Power	 i	 Info / Angle
 1	 1	 TXT	 Text / Goto
 2	 2	 AUX	 Shift + 7
 3	 3	 Blue / R	 Blue / Prime Video / Random
 *+	 >>I / Preset+	 Up	 Up
 4	 4	 P+	 CH+ / Page+
 5	 5	 Right	 Right
 6	 6	 Vol+	 Vol+
 -*	 I<< / Preset-	 Yellow	 Yellow / YouTube / Repeat
 7	 7	 OK	 OK
 8	 8	 Green/Timer	 Sleep / Timer
 9	 9	 Green/Timer	 Green / APP / Repeat
 O+	 >> / Tune+	 Left	 Left
 -O	 << / Tune-	 Vol-	 Vol-
 0/AV	 AV / Input / RDS	 Down	 Down
 0/AV	 0	 P-	 CH- / Page-
 P/C-ATS	 Display / Media	 Red	 Red / Netflix / Search



























	Original	Replacement	Original	Replacement
	Audio / Mute	 Mute / Dimmer		
	Audio / Mute	 Audio / Lang I/II		









































































	Original	Replacement	Original	Replacement
	Power			
	<			
	>			
	Play			
	Pause			
	<<			
	>>			
	Stop			
	Rec			
	P+			
	P-			





Original	Replacement	Original	Replacement
 Power	 Power	 i	 Info / Angle
 1	 1	 TXT	 Text / Goto
 2	 2	 AUX	 Shift + 7
 3	 3	 Blue / R	 Blue / Prime Video / Random
 *+	 >>I / Preset+	 P+	 CH+ / Page+
 4	 4	 Up	 Up
 5	 5	 Right	 Right
 6	 6	 Vol+	 Vol+
 -*	 I<< / Preset-	 Yellow	 Yellow / YouTube / Repeat
 7	 7	 OK	 OK
 8	 8	 Green/Timer	 Green / APP / Repeat
 9	 9	 Green/Timer	 Sleep / Timer
 O+	 >> / Tune+	 Left	 Left
 -O	 << / Tune-	 Vol-	 Vol-
 0/AV	 AV / Input / RDS	 P-	 CH- / Page-
 0/AV	 0	 Down	 Down
 P/C-ATS	 Display / Media	 Red	 Red / Netflix / Search





	Original	Replacement		Original	Replacement
	Audio / Mute	 Mute / Dimmer			
	Audio / Mute	 Audio / Lang I/II			

