



Original	Replacement

Original	Replacement









































































Original	Replacement
 Yellow / Subtitle	 Subt
 TV / AV	 AV
 Green / P/N	 Green
 SAT	 Media
 TV / Radio	 TV/R
 EPG	 Guide

Original	Replacement





Original	Replacement	Original	Replacement
 Power	 Power	 CH+	 Ch +
 Red	 Red	 CH-	 Ch -
 Green	 Green	 Up	 Up
 Yellow	 Yellow	 Down	 Down
 Blue	 Blue	 Right	 Right
 TV/SAT	 AV	 Left	 Left
 TV/Radio	 TV/R	 OK	 Ok
 Zoom	 Eject	 Vol+	 Vol +
 List	 List	 Vol-	 Vol -
 Audio	 Dual	 P+	 >>
 EPG	 Guide	 P-	 <<
 Timer	 Shift + AV	 Recall	 Pre Ch
 Text	 Text	 FAV	 Shift + Pre Ch
 Exit	 Exit	 1	 1
 Menu	 Menu	 2	 2
 M/P	 Media	 3	 3
 Mute	 Mute	 4	 4





Original	Replacement	Original	Replacement
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Info		Info
	Pause		Pause

