

























Original	Replacement
PP	PP
	Back / Return
	Power
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
P<P	Fav / Marker / PC
0	0
--	Guide / EPG / -/--
	Menu / Home
	Info / Angle
	Audio / Lang I/II

Original	Replacement
	Mute / Dimmer
	Left
	Up
	Right
	OK
	Down
	Vol-
	Vol+
	CH- / Page-
	CH+ / Page+
	Red / Netflix / Search
	Sound / Title
	Green / APP / Repeat
	Picture / Format
	Yellow / YouTube / Repeat
	Blue / Prime Video / Random
	Text / Goto



