












































| Original | Replacement | Original | Replacement |
|---|-------------|---|----------------------------|
|  | Power |  | Power |
|  | Mute |  | Mute / Dimmer |
|  | 1 |  | 1 |
|  | 2 |  | 2 |
|  | 3 |  | 3 |
|  | 4 |  | 4 |
|  | 5 |  | 5 |
|  | 6 |  | 6 |
|  | 7 |  | 7 |
|  | 8 |  | 8 |
|  | 9 |  | 9 |
|  | -/-- |  | Shift + Guide / EPG / -/-- |
|  | 0 |  | 0 |
|  | Recall |  | Back / Return |
|  | P.Mode |  | Picture / Format |
|  | S.Mode |  | Sound / Title |
|  | FAV |  | Fav / Marker / PC |
|  | Vol+ |  | Vol+ |
|  | MTS I/II |  | Audio / Lang I/II |
|  | CH+ |  | CH+ / Page+ |
|  | Vol- |  | Vol- |
|  | Sub-T |  | Subtitle / EQ |
|  | CH- |  | CH- / Page- |
|  | Aspect |  | Shift + Picture / Format |
|  | Freeze |  | Shift + Pause / Step / |
|  | Sleep |  | Sleep / Timer |
|  | Source |  | AV / Input / RDS |
|  | Up |  | Up |
|  | Display |  | Display / Media |
|  | Left |  | Left |
|  | OK |  | OK |
|  | Right |  | Right |
|  | Menu |  | Menu / Home |
|  | Down |  | Down |





| Original | | Replacement | | Original | | Replacement | |
|---|--------------|---|------------------------------|---|---------|---|--------------------|
|  | Exit |  | Exit / Cancel / Clear |  | List |  | Smart / List |
|  | Red |  | Red / Netflix / Search |  | T.Shift |  | TV/Radio / |
|  | Green |  | Green / APP / Repeat |  | USB |  | Shift + 8 |
|  | Yellow |  | Yellow / YouTube / Repeat |  | EPG |  | Guide / EPG / -/-- |
|  | Blue |  | Blue / Prime Video / Random | | | | |
|  | << / Text/CC |  | << / Tune- | | | | |
|  | << / Text/CC |  | Text / Goto | | | | |
|  | Play/Pause / |  | Play / Slow | | | | |
|  | Play/Pause / |  | Pause / Step / Freeze | | | | |
|  | >> / Reveal |  | >> / Tune+ | | | | |
|  | I<< / Hold |  | I<< / Preset- | | | | |
|  | I<< / Hold |  | Shift + Stop / | | | | |
|  | >>I / Size |  | >>I / Preset+ | | | | |
|  | >>I / Size |  | Zoom / Size | | | | |
|  | Stop / Index |  | Stop / Hold | | | | |
|  | Root |  | Info / Angle | | | | |
|  | Repeat |  | Shift + Green / APP / Repeat | | | | |

