







































































Original	Replacement	Original	Replacement
	Power		Power
	Audio		Dual
	Subtl		Subt
	Sleep		Sleep
	USB		Media
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	DTV/Radio		TV/R
	Recall		Pre Ch
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	Text		Text
	P+		Ch +
	P-		Ch -
	Info		Info
	Entrada		AV
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Menu		Menu
	Salir		Exit
	Imagen		Format
	Sonido		Shift + Dual





	Original	Replacement	Original	Replacement
	Tamaño	 3D		
	Guía	 GUIDE		
	Play			
	Pause/TS			
	Detener			
	Grabar			
	List			
	Red			
	I<<			
	Green			
	>>I			
	Yellow			
	<<			
	Blue			
	>>			

