





































Original	Sustituto		
	Power		Power
	Red / ↑		Red / Netflix / Search
	Green / ↓		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	Blue		Blue / Prime Video / Random
	M		Menu / Home
	Return		Back / Return
	Up		Up
	Left		Left
	OK		OK
	Right		Right
	Down		Down
	Source		AV / Input / RDS
	Presets		D.Menu / Top
	Info		Info / Angle
	EPG		Guide / EPG / -/--
	Vol+		Vol+

Original	Sustituto		
	Mute		Mute / Dimmer
	P+		CH+ / Page+
	Vol-		Vol-
	P-		CH- / Page-
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	FAV		Shift + Fav / Marker / PC
	0		0
	Recall		Fav / Marker / PC
	Screen		Picture / Format



