



| Original | Sustituto |
|------------|-------------------------------|
| Power | Power |
| 1 | 1 |
| 2 | 2 |
| 3 | 3 |
| 4 | 4 |
| 5 | 5 |
| 6 | 6 |
| 7 | 7 |
| 8 | 8 |
| 9 | 9 |
| 0 | 0 |
| Cancel | Shift + Exit / Cancel / Clear |
| Audio | Audio / Lang I/II |
| Open/Close | Eject / Surround |
| PIP | Picture / Format |
| Internet | Smart / List |
| Audio | Sound / Title |

| Original | Sustituto |
|-------------|-----------------------|
| << Search | << / Tune- |
| Play | Play / Slow |
| Search >> | >> / Tune+ |
| I<< Skip | I<< / Preset- |
| Pause | Pause / Step / Freeze |
| Skip >>I | >>I / Preset+ |
| Stop | Stop / Hold |
| Exit | Exit / Cancel / Clear |
| Status | Info / Angle |
| Option | Setup / OPT / |
| Return | Back / Return |
| Top Menu | D.Menu / Top |
| Home | Menu / Home |
| Pop-Up Menu | Display / Media |
| Up | Up |
| Down | Down |
| Right | Right |



Secondary

