































Original	Sustituto	Original	Sustituto
 Power	 Power	 SRND Mode >	 Ch +
 Vol+	 Vol +	 BAL CHK	 Dual
 Vol-	 Vol -	 Delay Time >	 Up
 Phono	 1	 < Delay Time	 Down
 AUX1	 2	 Pause Tape	 Pause
 AUX 2	 3	 Play Tape	 Play
 Tape 1	 4	 Stop Tape	 Stop
 Tape 2	 5	 >> Tape	 >>
 Video 1	 6	 Rec/Zone	 Options
 Video 2	 7	 << Tape	 <<
 Video 3	 8	 Band	 Smart
 Off	 Exit	 Rec Tape	 Rec
 A Tun	 Ok	 On Screen	 Info
 Tuning >	 Right	 Tuner	 Media
 < Tuning	 Left		
 CTR ECS	 List		
 < SRND Mode	 Ch -		



