



Original	Sustituto
 Power	 Power
 File Mode	 D.Menu / Top
 Setup	 Setup / OPT /
 Suspend	 AV / Input / RDS
 Page Up	 CH+ / Page+
 USB	 Shift + 8
 TV Mode	 TV/Radio /
 Mute	 Mute / Dimmer
 Page Down	 CH- / Page-
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8

Original	Sustituto
 9	 9
 0	 0
 Delete	 Guide / EPG / -/-
 CAPS/NUM.	 Fav / Marker / PC
 Return	 Back / Return
 Source	 Eject / Surround
 Info	 Info / Angle
 Home	 Shift + Menu /
 Up	 Up
 Down	 Down
 Left	 Left
 Right	 Right
 Enter	 OK
 Menu	 Menu / Home
 I<<	 I<< / Preset-
 Play	 Play / Slow
 >>I	 >>I / Preset+



