





Original	Sustituto
	 Power
	 Mute / Dimmer
	 1
	 2
	 3
	 4
	 5
	 6
	 7
	 8
	 9
	 0
	 TV/Radio /
	 Display / Media
	 Menu / Home
	 Guide / EPG / -/-
	 Info / Angle

Original	Sustituto
	 Exit / Cancel / Clear
	 Up
	 CH+ / Page+
	 Down
	 CH- / Page-
	 OK
	 Right
	 Vol+
	 Left
	 Vol-
	 Smart / List
	 Pause / Step / Freeze
	 Picture / Format
	 Shift + CH+ /
	 Shift + CH- /
	 >> / Preset+
	 I<< / Preset-





Original	Sustituto
 UHF	 AV / Input / RDS
 Red / Recall	 Red / Netflix / Search
 Red / Recall	 Back / Return
 Green / Audio	 Green / APP / Repeat
 Green / Audio	 Audio / Lang I/II
 Yellow / Text	 Yellow / YouTube / Repeat
 Yellow / Text	 Text / Goto
 Blue	 Blue / Prime Video / Random

Original	Sustituto

