








































Original	Sustituto
	 Power
	 Display / Media
	 Mute / Dimmer
	 Pause / Step / Freeze
	 1
	 2
	 3
	 4
	 5
	 6
	 7
	 8
	 9
	 Info / Angle
	 0
	 Back / Return
	 Red / Netflix / Search

Original	Sustituto
	 Blue / Prime Video / Random
	 Green / APP / Repeat
	 Yellow / YouTube / Repeat
	 Shift + Picture / Format
	 Audio / Lang I/II
	 Menu / Home
	 AV / Input / RDS
	 Exit / Cancel / Clear
	 Up
	 CH+ / Page+
	 Left
	 OK
	 Right
	 Down
	 Vol+
	 CH- / Page-
	 Vol-





Original	Sustituto
 Picture	 Picture / Format
 Sound	 Sound / Title
 Text	 Text / Goto
 HDMI	 Shift + 0
 VGA	 Shift + 4
 Guide/Zoom	 Zoom / Size
 Guide/Zoom	 Guide / EPG / -/--
 Index/Subtitle	 Subtitle / EQ
 Sleep/Hold	 Sleep / Timer
 Sleep/Hold	 Stop / Hold
 Lang/Cancel	 Shift + Exit / Cancel / Clear
 Lang/Cancel	 Shift + Audio / Lang I/II
 FAV/Sub.code	 Fav / Marker / PC
 TV/Reveal	 Smart / List
 Comp./Mix	 Setup / OPT /

Original	Sustituto

