
































Original	Sustituto
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 FAV	 Pre Ch
 TXT	 Text
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue

Original	Sustituto
 Guide	 Guide
 ?	 Dual
 Exit	 Exit
 Menu	 Menu
 Tools	 Options
 Back	 Back
 @	 Smart
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 Source	 AV
 P+	 Ch +





	Original	Sustituto	Original	Sustituto
	P-	 Ch -		
	I<	 I<<		
	>I	 >>I		
	<<	 <<		
	>>	 >>		
	Rec	 Rec		
	Play	 Play		
	Pause	 Pause		
	Stop	 Stop		
	3D	 3D		
	OQ	 Format		
	[...]..	 Subt		
	Netflix	 Shift + Media		
	My Media	 Media		

