



Original	Sustituto
Power	Power
Input 1	Shift + 1
Input 2	Shift + 2
Input 3	Shift + 3
Input 4	Shift + 4
Input 5	Shift + 5
PC	Shift + Fav / Marker / PC
HMG	Shift + 6
[i+]/Timer/Info	Sleep / Timer
[i+]/Timer/Info	Info / Angle
[TV]	Shift + Red / Netflix /
[←]	Shift + Yellow / YouTube /
[→]	Shift + Green / APP /
CTRL HDMI	Picture / Format
1	1
2	2
3	3

Original	Sustituto
4	4
5	5
6	6
7	7
8	8
9	9
EPG/DVD Top Menu/Guide	D.Menu / Top
EPG/DVD Top Menu/Guide	Guide / EPG / -/-
0	0
TV/DTV/SAT	AV / Input / RDS
P+	CH+ / Page+
CH return	Fav / Marker / PC
Vol+	Vol+
P-	CH- / Page-
Mute	Mute / Dimmer
Vol-	Vol-
Exit	Exit / Cancel / Clear







































Original	Sustituto
	Up
	Setup / OPT /
	Left
	OK
	Right
	Menu / Home
	Down
	Back / Return
	Red / Netflix / Search
	Rec / Rec Mode
	Green / APP / Repeat
	Pause / Step / Freeze
	Yellow / YouTube / Repeat
	Stop / Hold
	Blue / Prime Video / Random
	Play / Slow
	I<< / Preset-

Original	Sustituto
	Subtitle / EQ
	>> / Preset+
	Shift + Display / Media
	<< / Tune-
	Shift + Smart / List
	>> / Tune+
	Text / Goto
	Audio / Lang I/II
	Smart / List
	Display / Media





Original	Sustituto
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 EPG/DVD Top Menu/Guide	 Guide / EPG / -/-
 EPG/DVD Top Menu/Guide	 D.Menu / Top
 0	 0
 Vol+ Tv	 Vol+
 Mute Tv	 Mute / Dimmer
 Vol- Tv	 Vol-
 Up	 Up

Original	Sustituto
 Left	 Left
 Enter	 OK
 Right	 Right
 Menu/Home	 Menu / Home
 Down	 Down
 Return	 Back / Return
 Pause	 Pause / Step / Freeze
 Stop	 Stop / Hold
 Play	 Play / Slow
 I<<	 I<< / Preset-
 >>I	 >>I / Preset+
 <<	 << / Tune-
 >>	 >> / Tune+



