





























































Original	Sustituto	Original	Sustituto
 Power	 Power	 Recall	 Back
 Mute	 Mute	 Timer/[≡i]	 List
 Info	 Timer/[X]	 Sleep	
 TV/R	 Vol+	 Vol +	
 AV	 Vol-	 Vol -	
 Smart	 Prog+	 Ch +	
 1	 1	 Prog-	 Ch -
 2	 2	 (↔)	 Dual
 3	 3	 Menu	 Menu
 4	 4	 Up	 Up
 5	 5	 Left	 Left
 6	 6	 OK	 Ok
 7	 7	 Right	 Right
 8	 8	 Down	 Down
 9	 9	 [≡]	 Text
 0	 0	 Red/Sound	 Red
 -/--	 Guide	 Green/*	 Green



