











































































Original	Recharge	Original	Recharge
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	M		Menu
	E		Exit
	i		Info
	Rec		Rec
	Pause		Pause
	OK		Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	<<		<<
	Stop		Stop
	Play		Play
	>>		>>
	Mute/Timer		Mute
	[]		Subt
	T		TV/R
	Guide/000		Guide
	V≡/LP		Format









































































Original		Recharge		Original		Recharge	
	[*]/SV		3D				
	Sound		Dual				






Original	Recharge	Original	Recharge
	Power		Power
	[]		Subt
	Mute/Timer		Mute
	Guide/000		Guide
	V= / LP		Format
	[*] / SV		3D
	Sound		Dual
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	M		Menu
	E		Exit
	T		TV/R
	i		Info
	OK		Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	<<		<<
	Stop		Stop
	Play		Play
	>>		>>









































































Original		Recharge		Original		Recharge	
	Pause		Pause				
	Rec		Rec				





Original	Recharge	Original	Recharge
 Power	 Power	 M	 Menu
 []	 Subt	 E	 Exit
 Mute/Timer	 Mute	 T	 TV/R
 Guide/000	 Guide	 OK	 Ok
 V= / LP	 Format	 Up	 Up
 [*] / SV	 3D	 Down	 Down
 Sound	 Dual	 Right	 Right
 1	 1	 Left	 Left
 2	 2	 Red	 Red
 3	 3	 Green	 Green
 4	 4	 Yellow	 Yellow
 5	 5	 Blue	 Blue
 6	 6	 <<	 <<
 7	 7	 Stop	 Stop
 8	 8	 Play	 Play
 9	 9	 >>	 >>
 0	 0	 Pause	 Pause

