

























































	Original	Recharge		Original	Recharge
	Power		Power		Up
	Mute		Mute		Down
	CD/SD/USB		Smart		Right
	AUX/BT		3D		Left
	Radio		TV/R		Ok
	1		1		Play
	2		2		Pause
	3		3		Vol +
	4		4		Vol -
	5		5		Audio/DSC
	6		6		Back
	7		7		X/INT
	8		8		Options
	9		9		Stop
	0		0		Stereo
	Display		Info		Dual
	*/Menu		Menu		Timer/Prog
					Shift + Sleep
					AV
					Media



