


































































| Original | Rechange | Original | Rechange |
|--|--|--|---|
|  Standby |  Power |  TV / Radio |  TV/Radio / |
|  Mute |  Mute / Dimmer |  Menu |  Menu / Home |
|  1 |  1 |  Up |  Up |
|  2 |  2 |  Exit |  Exit / Cancel / Clear |
|  3 |  3 |  Left |  Left |
|  EPG |  Guide / EPG / -/-- |  OK |  OK |
|  4 |  4 |  Right |  Right |
|  5 |  5 |  Record |  Rec / Rec Mode |
|  6 |  6 |  Down |  Down |
|  Audio |  Audio / Lang I/II |  Stop |  Stop / Hold |
|  7 |  7 |  Vol + |  Vol+ |
|  8 |  8 |  CH + |  CH+ / Page+ |
|  9 |  9 |  Vol - |  Vol- |
|  Subtitle |  Subtitle / EQ |  TTX |  Text / Goto |
|  Info |  Info / Angle |  FAV |  Fav / Marker / PC |
|  0 |  0 |  CH - |  CH- / Page- |
|  Recall |  Back / Return |  Media |  Display / Media |



