





































































Original	Rechange
 Power	 Power
 Mute	 Mute / Dimmer
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 List	 Smart / List
 0	 0
 Recall	 Back / Return
 P.Mode	 Picture / Format
 S.Mode	 Sound / Title
 Sleep	 Sleep / Timer

Original	Rechange
 Vol +	 Vol+
 MTS	 Info / Angle
 CH +	 CH+ / Page+
 Vol -	 Vol-
 Aspect	 Shift + Picture / Format
 CH -	 CH- / Page-
 Guide	 Guide / EPG / -/-
 Home	 Shift + Menu /
 Rec	 Rec / Rec Mode
 Menu	 Menu / Home
 Up	 Up
 Source	 AV / Input / RDS
 Left	 Left
 Enter	 OK
 Right	 Right
 Exit	 Exit / Cancel / Clear
 Down	 Down



