



Original		Rechange		Original		Rechange	
	Power		Power		Display		Info
	Mute		Mute		Sleep		Sleep
	1		1		Vol+		Vol +
	2		2		Vol-		Vol -
	3		3		CH+		Ch +
	4		4		CH-		Ch -
	5		5		FAV/List		Shift + Pre Ch
	6		6		Clock		Shift + AV
	7		7		List		List
	8		8		Tv/Radio		TV/R
	9		9		Aspect		Format
	0		0		Freeze		Pause
	-/--		Guide		Index		Options
	Recall		Pre Ch		Cancel		Back
	Menu		Menu		Subpage		Subt
	Source		AV		Text		Text
	Exit		Exit		Size		Eject





Original	Rechange	Original	Rechange
 Reveal	 Media		
 Hold	 Dual		
 Mix	 Shift + Media		
 Red	 Red		
 Green	 Green		
 Yellow	 Yellow		
 Cyan	 Blue		
 Nicam	 Smart		
 P.Mode	 Shift + Format		
 S.Mode	 Shift + Dual		
 OK	 Ok		
 Up	 Up		
 Down	 Down		
 Right	 Right		
 Left	 Left		

