

























































Original	Recharge	Original	Recharge
 Power	 Power	 TV/Radio	 TV/R
 Mute	 Mute	 Recall	 Back
 Red/Repeat	 Red	 Menu	 Menu
 Green/Prog	 Green	 Text	 Text
 Yellow/Slow	 Yellow	 Exit	 Exit
 Blue/Angle	 Blue	 Guide	 Guide
 Play	 Play	 Source	 AV
 Pause	 Pause	 Up	 Up
 Stop	 Stop	 Down	 Down
 <<<	 <<<	 Right	 Right
 >>>	 >>>	 Left	 Left
 Goto/Fav	 Pre Ch	 Ok/Ch List	 Ok
 Eject	 Eject	 Vol +	 Vol +
 I<<<	 I<<<	 Vol -	 Vol -
 >>>I	 >>>I	 Info	 Info
 Setup	 Options	 Zoom	 Shift + Eject
 Vcr	 Format	 Ch +	 Ch +





	Original	Rechange	Original	Rechange
CH	Ch-	CH	Ch -	
1	1	1		
2	2	2		
3	3	3		
4	4	4		
5	5	5		
6	6	6		
7	7	7		
8	8	8		
9	9	9		
0	0	0		
AUDIO	Audio	SOUND DUAL		
SUBTITLE	Subtitle	AD SUBT		

