



















































Original	Recharge	Original	Recharge
Tape/Deck 1/2	 Blue		
 Play	 Play		
 <<	 <<		
 >>	 >>		
 Stop	 Stop		
 Rec/Rec Mute	 Rec		
 Pause	 Pause		
 Power	 Power		
Volume Down	 Vol -		
Volume Up	 Vol +		





Original	Recharge	
Power ON/Off		Power
Mute		Mute
Every Pop		Play
Tape 1 Stop		Stop
Preset Pause		Rec
Vol Rs-/Effect		Subt
Sleep		Sleep
CD Random		TV/R
Tape 2 Pre./eq		D. Menu
Repeat		Text
Vol Rs+/S.Mode		Eject
Input/Source		AV
CD/Theater		Menu
CD Play		Up
Display		Info
CD Rewind		Left
Stop		Ok

Original	Recharge	
CD F.FWD		Right
Funct./Direct		Exit
CD Pause		Down
Woofer/Speed		Back
Volume+		Vol +
Volume-		Vol -
Tape 1 Hall/Ats		Media
Pr 1		1
Pr 2		2
Pr 3		3
Pr 4		4
Pr 5		5
Pr 6		6
Pr 7		7
Pr 8		8
Pr 9		9
Mode		Guide





Original	Recharge	
Pr 0/10		0
Program		Pre Ch
Tape 1 Rec		Red
Tape 1 Rew		Green
Tape 1 Play		Yellow
Tape 1 F.FWD		Blue
Edit	+	Shift + Text
Fm Mode/Disc	+	Shift + Menu
Tuner/Bypass	+	Shift + Exit
Disc 1 Eject	+	Shift + 1
Disc 2	+	Shift + 2
Disc 3 Eject	+	Shift + 3
6 Ch/Geq	+	Shift + 6
+10/Next Sv+V	+	Shift + Guide

Original	Recharge

