



Original	Recharge
[+]	SIZE ZOOM Zoom / Size
Power	Power
Source/[?]	RDS AV INPUT AV / Input / RDS
>>	TUNE- >> / Tune+
Red/Rec	NETFLIX Red / Netflix / Search
Green	APP REPEAT Green / APP / Repeat
<<	TUNE- << / Tune-
Yellow	YouTube REPEAT A-B Yellow / YouTube / Repeat
Stop	HOLD Stop / Hold
Blue	Prime Video RANDOM Blue / Prime Video / Random
Play	SLOW Play / Slow
Radio	PROGRAM TV / RADIO TV/Radio /
[=]	GOTO TEXT Text / Goto
[]	TOP MENU D.MENU D.Menu / Top
Menu	HOME MENU Menu / Home
Up	Up
Down	Down

Original	Recharge
Left	Left
Right	Right
Vol+	VOL+ Vol+
Vol-	VOL- Vol-
Mute	DIMMER MUTE Mute / Dimmer
P+	CH PAGE+ CH+ / Page+
P-	CH PAGE- CH- / Page-
1	TV 1 1
2	DVD 2 2
3	CD - STB 3 3
4	VIDEO 4 4
5	TAPE 5 5
6	TUNER 6 6
7	AUX - HDD 7 7
8	USB 8 8
9	BLUETOOTH 9 9
0	HDMI - BAT 0 0





Original	Recharge
Power SAT	+ Shift + Power
Power	Power
Source/[?]	AV / Input / RDS
Source SAT	+ Shift + AV / Input / RDS
>>	>> / Tune+
Red SAT	Red / Netflix / Search
<<	<< / Tune-
Green SAT	Green / APP / Repeat
Yellow SAT	Yellow / YouTube / Repeat
Stop	Stop / Hold
Play	Play / Slow
Blue SAT	Blue / Prime Video / Random
Radio	TV/Radio /
[=]	Text / Goto
Up	Up
Up SAT	+ Shift + Up
Down	Down

Original	Recharge
Down SAT	+ Shift + Down
Left SAT	+ Shift + Left
Left	Left
Right SAT	+ Shift + Right
Right	Right
OK SAT	+ Shift + OK
OK	OK
[] SAT	+ Shift + Back / Return
[]	Back / Return
Menu SAT	D.Menu / Top
Menu	Menu / Home
Vol+	Vol+
Vol-	Vol-
Mute	Mute / Dimmer
P+ SAT	+ Shift + CH+ /
P+	CH+ / Page+
P- SAT	+ Shift + CH- /



Page-

























Original	Recharge
	CH PAGE / CH- / Page-
	SHIFT + 1 / Shift + 1
	1 / 1
	SHIFT + 2 / Shift + 2
	2 / 2
	SHIFT + 3 / Shift + 3
	3 / 3
	SHIFT + 4 / Shift + 4
	4 / 4
	SHIFT + 5 / Shift + 5
	5 / 5
	SHIFT + 6 / Shift + 6
	6 / 6
	SHIFT + 7 / Shift + 7
	7 / 7
	SHIFT + 8 / Shift + 8
	8 / 8

Original	Recharge
	SHIFT + 9 / Shift + 9
	9 / 9
	SHIFT + 0 / Shift + 0
	0 / 0
	INFO / Info / Angle
	AUDIO / Audio / Lang I/II
	PICTURE / Picture / Format
	Fav / Marker / PC





Original	Recharge
 Power	 Power
 >>	 >> / Tune+
 <<	 << / Tune-
 Stop	 Stop / Hold
 Play	 Play / Slow
 Radio	 TV/Radio /
 []	 Back / Return
 Up	 Up
 Down	 Down
 Left	 Left
 Right	 Right
 Vol+	 Vol+
 Vol-	 Vol-
 Mute	 Mute / Dimmer
 P+	 CH+ / Page+
 P-	 CH- / Page-
 1	 1

Original	Recharge
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 [i+]	 Info / Angle
 I-II	 Audio / Lang I/II





Original	Recharge
Power AMP	Shift + Power
Power	Power
Source/[?]	AV / Input / RDS
>>	>> / Tune+
>> AMP	>>I / Preset+
Red	Red / Netflix / Search
Rec	Rec / Rec Mode
<< AMP	I<< / Preset-
Green	Green / APP / Repeat
<<	<< / Tune-
Yellow	Yellow / YouTube / Repeat
Stop	Stop / Hold
Blue	Blue / Prime Video / Random
Play	Play / Slow
Radio AMP	TV/Radio /
[=] AMP	Text / Goto
[]	Back / Return

Original	Recharge
Menu	Menu / Home
Menu AMP	D.Menu / Top
Up AMP	Shift + Up
Up	Up
Down	Down
Down AMP	Shift + Down
Left	Left
Left AMP	Shift + Left
Right	Right
Right AMP	Shift + Right
OK	OK
OK AMP	Shift + OK
Vol+ AMP	Shift + Smart / List
Vol+	Vol+
Vol-	Vol-
Mute AMP	Shift + Mute / Dimmer
Mute	Mute / Dimmer





Original	Rechange
P+	CH+ / Page+
P+ AMP	SHIFT + CH+ /
P- AMP	SHIFT + CH- /
P-	CH- / Page-
1 AMP	SHIFT + TV 1
1	TV 1
2 AMP	SHIFT + DVD 2
2	DVD 2
3 AMP	SHIFT + CD-STB 3
3	CD-STB 3
4 AMP	SHIFT + VIDEO 4
4	VIDEO 4
5 AMP	SHIFT + TAPE 5
5	TAPE 5
6 AMP	SHIFT + TUNER 6
6	TUNER 6
7 AMP	SHIFT + AUX-HDD 7

Original	Rechange
7	AUX-HDD 7
8 AMP	SHIFT + USB 8
8	USB 8
9 AMP	SHIFT + BLUETOOTH 9
9	BLUETOOTH 9
0 AMP	SHIFT + HDMI-BAT 0
0	HDMI-BAT 0
[i+]	ANGLE INFO
I-II	LANG I/II AUDIO
[1 2] AMP	EQ SUBTITLE
[+]	SIZE ZOOM
[<>]	FORMAT PICTURE
P<P	PC FAV MARKER
Smart	LIST SMART
[]/Smart	MEDIA DISPLAY

