







































































Original		Rechange		Original		Rechange	
<<		<< / Tune-		8		8	
>>		>> / Tune+		9		9	
I<<		I<< / Preset-		[≡?]/Source		Eject / Surround	
>>I		>>I / Preset+		0		0	
Play		Play / Slow		O)/I/II/Audio		Audio / Lang I/II	
Pause		Pause / Step / Freeze		Menu		Menu / Home	
Stop		Stop / Hold		Exit		Exit / Cancel / Clear	
	Power		Power		Up		Up
	[≡i]/Info		Info / Angle		Left		Left
	Mute		Mute / Dimmer		Enter		OK
	1		1		Right		Right
	2		2		Down		Down
	3		3		CH+		CH+ / Page+
	4		4		Index		Display / Media
	5		5		Vol+		Vol+
	6		6		CH-		CH- / Page-
	7		7		List		Smart / List



