




Original	Recharge
	 Menu / Home
	 Up
	 Power
	 Left
	 OK
	 Right
	 Down
	 Exit / Cancel / Clear
	 1
	 2
	 3
	 4
	 5
	 6
	 7
	 8
	 9

Original	Recharge
	 AV / Input / RDS
	 0
	 CH- / Page-
	 CH+ / Page+
	 << / Tune-
	 Play / Slow
	 >> / Tune+
	 Rec / Rec Mode
	 Stop / Hold
	 Pause / Step / Freeze
	 Picture / Format
	 Info / Angle
	 Back / Return

