




































Original	Rechange
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Menu	 Menu
 Exit	 Exit
 Up	 Up
 Down	 Down
 Right	 Right

Original	Rechange
 Left	 Left
 OK	 Ok
 CH+	 Ch +
 CH-	 Ch -
 Vol+	 Vol +
 Vol-	 Vol -
 Red	 Red
 Yellow	 Yellow
 Blue	 Blue
 Green	 Green
 EPG	 Guide
 Subtitle	 Subt
 TTX	 Text
 Audio	 Dual
 i	 Info
 FAV	 Pre Ch
 Tv/Radio	 TV/R





Original		Rechange		Original		Rechange	
	Video		Smart				
	Scan		Media				
	Device		Options				
	File		List				
	Zoom		Eject				
	Roll		AV				
	Record		Rec				
	Prev.		I<<				
	Next		>>I				
	Play		Play				
	Pause		Pause				
	<<		<<				
	>>		>>				

