

















































Original	Rechange	Original	Rechange
 Power	 Power	 Menu	 Menu
 Mute	 Mute	 EPG	 Guide
 1	 1	 Exit	 Exit
 2	 2	 Up / CH + / I<<	 Up
 3	 3	 Down / CH - / >>I	 Down
 4	 4	 Right / Vol +	 Right
 5	 5	 Left / Vol -	 Left
 6	 6	 OK	 Ok
 7	 7	 Up / CH + / I<<	 I<<
 8	 8	 Down / CH - / >>I	 >>I
 9	 9	 Up / CH + / I<<	 Ch +
 0	 0	 Down / CH - / >>I	 Ch -
 FAV	 Shift + Pre Ch	 Left / Vol -	 Vol -
 Recall	 Pre Ch	 Right / Vol +	 Vol +
 Game	 Media	 Red / Zoom	 Red
 Auto	 Smart	 Green / Lan/Audio	 Green
 Info	 Info	 Yellow /	 Yellow

Original	Rechange	Original	Rechange
 Menu	 Menu	 Menu	 Menu
 EPG	 Guide	 Exit	 Exit
 Up / CH + / I<<	 Up	 Down / CH - / >>I	 Down
 Right / Vol +	 Right	 Left / Vol -	 Left
 OK	 Ok	 Up / CH + / I<<	 I<<
 Down / CH - / >>I	 >>I	 Up / CH + / I<<	 Ch +
 Left / Vol -	 Vol -	 Down / CH - / >>I	 Ch -
 Right / Vol +	 Vol +	 Up / CH + / I<<	 Ch +
 Red / Zoom	 Red	 Down / CH - / >>I	 Ch -
 Green / Lan/Audio	 Green	 Up / CH + / I<<	 Ch +
 Yellow /	 Yellow	 Down / CH - / >>I	 Ch -



Play/Pause

