Original		Replacement	
Power	Power	Power	
INPUT	Input	TIMER AV	AV
P.Mode	P. Mode	SHIFT + PICTURE FORMAT	Shift + Format
P.Size	P. Size	PICTURE FORMAT	Format
S.Mode	S. Mode	SHIFT + SOUND DUAL	Shift + Dual
SLEEP	Sleep	PROG SLEEP	Sleep
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
GUIDE	Guide	-/-- GUIDE	Guide

Original		Replacement	
INFO	Info	DISPLAY INFO	Info
VOL	Vol +	+ VOL	Vol +
VOL	Vol -	VOL −	Vol -
CH	CH+	+ CH	Ch +
CH	CH-	CH −	Ch -
CH.List	CH. List	DISC NAV LIST	List
	Mute	MUTE	Mute
	Home	HOME SMART	Smart
	☼	TOP MENU MENU	Menu
	[≡]	REPEAT TEXT	Text
BACK	Back	RETURN BACK	Back
EXIT	Exit	CLEAR EXIT	Exit
OK	OK	OK	Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left

Original		Replacement		Original	Replacement
	Red	A	Red		
	Green	B	Green		
	Yellow	C	Yellow		
	Blue	D	Blue		
	<<	<<	<<		
	>>	>>	>>		
	Play	PLAY MODE	Play		
	Stop		Stop		
	Pause		Pause		
	Rec	REC MODE	Rec		
Subtitle	Subtitle	AD SUBT	Subt		
Language	Language	SOUND DUAL	Dual		
TXT	TXT	SEARCH TV/R	TV/R		
amazon	Amazon	SHIFT + APP MEDIA	Shift + Media		
YouTube	YouTube	APP MEDIA	Media		
NETFLIX	Netflix	SHIFT + HOME SMART	Shift + Smart		
Play	FPlay	E-MANUAL D.MENU	D. Menu		