Original		Replacement	
	Power		Power
	Last		Pre Ch
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	TV/R		TV/R
	Audio		Dual
	Info		Info
	Mode		D. Menu

Original		Replacement	
	Favor		Options
	Menu		Menu
	Sub-T		Subt
	Exit		Exit
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	CH+		Ch +
	CH-		Ch -
	Vol +		Vol +
	Vol -		Vol -
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue

Original		Replacement		Original		Replacement	
EPG	EPG	-/-- GUIDE	Gui de				
TEXT	Text	REPEAT TEXT	Text				

Original	Replacement	Original	Replacement
Power	Power	Favor	Options
Last	Pre Ch	Menu	Menu
Mute	Mute	Sub-T	Subt
1	1	Exit	Exit
2	2	Up	Up
3	3	Down	Down
4	4	Right	Right
5	5	Left	Left
6	6	OK	Ok
7	7	CH+	Ch +
8	8	CH-	Ch -
9	9	Vol +	Vol +
0	0	Vol -	Vol -
TV/R	TV/R	Red	Red
Audio	Dual	Green	Green
Info	Info	Yellow	Yellow
Mode	D. Menu	Blue	Blue

Original	Replacement	Original	Replacement
EPG	GUIDE Gui de		
Text	REPEAT TEXT Text		

Original	Replacement	Original	Replacement
Power	Power	Favor	Options
Last	Pre Ch	Menu	Menu
Mute	Mute	Sub-T	Subt
1	1	Exit	Exit
2	2	Up	Up
3	3	Down	Down
4	4	Right	Right
5	5	Left	Left
6	6	OK	Ok
7	7	CH+	Ch +
8	8	CH-	Ch -
9	9	Vol +	Vol +
0	0	Vol -	Vol -
TV/R	TV/R	Red	Red
Audio	Dual	Green	Green
Info	Info	Yellow	Yellow
Mode	D. Menu	Blue	Blue

Original	Replacement	Original	Replacement
EPG	GUIDE Gui de		
Text	REPEAT TEXT Text		