Original		Replacement	
ACOU	ACOU	REPEAT TEXT	Text
FM/AM	FM/AM	TIMER AV	AV
CD	CD	PICTURE FORMAT	Format
TV	TV	ECO 3D	3D
CDV	CDV	A	Red
PHONO	Phono	B	Green
TAPE	Tape	C	Yellow
VCR	VCR	D	Blue
REAR	Rear	CLEAR EXIT	Exit
FRONT	Front	RETURN BACK	Back
UP	Volume Up	+ VOL	Vol +
DOWN	Volume Down	VOL −	Vol -
MUTE	Mute ACOU	MUTE	Mute
L	L ACOU	HOME SMART	Smart
R	R ACOU	APP MEDIA	Media
1	1 ACOU	1	1
2	2 ACOU	2	2

Original		Replacement	
3	3 ACOU	3	3
4	4 ACOU	4	4
5	5 ACOU	5	5
6	6 ACOU	6	6
7	7 ACOU	7	7
8	8 ACOU	8	8
9	9 ACOU	9	9
10/0	10/0 ACOU	0	0
11/+	11/+ ACOU	-/-- GUIDE	Guide
12/-	12/- ACOU	FAV PRE-CH	Pre Ch
MEMO CH/PGM	Memo/CH/PGM TV	SETTINGS OPT	Options
MODE	Mode ACOU	AD SUBT	Subt
MODE	Mode TV	SHIFT + AD SUBT	Shift + Subt
UP	Volume Up TV	▶	Right
DOWN	Volume Down	◀	Left
MUTE	Mute TV	SHIFT + MUTE	Shift + Mute
L	L TV	SHIFT + HOME SMART	Shift + Smart

Original	Replacement	Original	Replacement
R TV	SHIFT + APP MEDIA Shift + Media		
Memo/CH/PGM	SHIFT + SETTINGS OPT Shift + Options		
AMS/'/'' TV	SHIFT + SOUND DUAL Shift + Dual		
1 TV	SHIFT + 1 Shift + 1		
2 TV	SHIFT + 2 Shift + 2		
3 TV	SHIFT + 3 Shift + 3		
4 TV	SHIFT + 4 Shift + 4		
5 TV	SHIFT + 5 Shift + 5		
6 TV	SHIFT + 6 Shift + 6		
7 TV	SHIFT + 7 Shift + 7		
8 TV	SHIFT + 8 Shift + 8		
9 TV	SHIFT + 9 Shift + 9		
10/0 TV	SHIFT + 0 Shift + 0		
11/+ TV	SHIFT + -/-- GUIDE Shift + Guide		
12/- TV	SHIFT + FAV PRE-CH Shift + Pre Ch		

Original		Replacement	
UP	Volume Up CD	+ VOL	Vol +
DOWN	Volume Down	VOL −	Vol -
MUTE	Mute CD	MUTE	Mute
L	L CD	HOME SMART	Smart
R	R CD	APP MEDIA	Media
FRONT	Front	RETURN BACK	Back
REAR	Rear	CLEAR EXIT	Exit
1	1 CD	1	1
2	2 CD	2	2
3	3 CD	3	3
4	4 CD	4	4
5	5 CD	5	5
6	6 CD	6	6
7	7 CD	7	7
8	8 CD	8	8
9	9 CD	9	9
10/0	0/10 CD	0	0

Original		Replacement	
11/+	11/+ CD	-/-- GUIDE	Guide
12/-	12/- CD	FAV PRE-CH	Pre Ch
MEMO CH/PGM	Memo/CH/PGM	SETTINGS OPT	Options
AMS -/--	AMS/''/'' CD	SOUND DUAL	Dual
▶	Play CD	PLAY MODE ▶	Play
⏸	Pause CD	⏸	Pause
■	Stop CD	■	Stop
⏪	<< CD	⏪	<<
⏩	>> CD	⏩	>>
UP	Volume Up	SHIFT + + VOL	Shift + Vol +
DOWN	Volume Down	SHIFT + VOL −	Shift + Vol -
MUTE	Mute Phono	SHIFT + MUTE	Shift + Mute
L	L Phono	SHIFT + HOME SMART	Shift + Smart
R	R Phono	SHIFT + APP MEDIA	Shift + Media
1	1 Phono	SHIFT + 1	Shift + 1
2	2 Phono	SHIFT + 2	Shift + 2
3	3 Phono	SHIFT + 3	Shift + 3

Original	Replacement	Original	Replacement
4 Phono	SHIFT + 4 Shift + 4		
5 Phono	SHIFT + 5 Shift + 5		
6 Phono	SHIFT + 6 Shift + 6		
7 Phono	SHIFT + 7 Shift + 7		
8 Phono	SHIFT + 8 Shift + 8		
9 Phono	SHIFT + 9 Shift + 9		
0/10 Phono	SHIFT + 0 Shift + 0		
Memo/CH/PGM	SHIFT + SETTINGS OPT Shift + Options		
Play Phono	SHIFT + PLAY MODE Shift + Play		
Pause Phono	SHIFT + Shift + Pause		
Stop Phono	SHIFT + Shift + Stop		
>> Phono	SHIFT + Shift + >>		
<< Phono	SHIFT + Shift + <<		

Original		Replacement	
UP	Volume Up	+ VOL	Vol +
DOWN	Volume Down	VOL −	Vol -
MUTE	Mute FM/AM	MUTE	Mute
FRONT	Front	RETURN BACK	Back
REAR	Rear	CLEAR EXIT	Exit
L	L FM/AM	HOME SMART	Smart
R	R FM/AM	APP MEDIA	Media
1	1 FM/AM	1	1
2	2 FM/AM	2	2
3	3 FM/AM	3	3
4	4 FM/AM	4	4
5	5 FM/AM	5	5
6	6 FM/AM	6	6
7	7 FM/AM	7	7
8	8 FM/AM	8	8
9	9 FM/AM	9	9
10/0	10/0 FM/AM	0	0

Original		Replacement	
11/+	11/+ FM/AM	-/-- GUIDE	Guide
12/-	12/- FM/AM	FAV PRE-CH	Pre Ch
MEMO CH/PGM	Memo/CH/PGM	SETTINGS OPT	Options
AMS -/--	AMS/''/'' FM/AM	SOUND DUAL	Dual
MODE	Mode FM/AM	AD SUBT	Subt
UP	Volume Up VCR	SHIFT + + VOL	Shift + Vol +
DOWN	Volume Down	SHIFT + VOL −	Shift + Vol -
MUTE	Mute VCR	SHIFT + MUTE	Shift + Mute
L	L VCR	SHIFT + HOME SMART	Shift + Smart
R	R VCR	SHIFT + APP MEDIA	Shift + Media
1	1 VCR	SHIFT + 1	Shift + 1
2	2 VCR	SHIFT + 2	Shift + 2
3	3 VCR	SHIFT + 3	Shift + 3
4	4 VCR	SHIFT + 4	Shift + 4
5	5 VCR	SHIFT + 5	Shift + 5
6	6 VCR	SHIFT + 6	Shift + 6
7	7 VCR	SHIFT + 7	Shift + 7

Original	Replacement	Original	Replacement
8 VCR	SHIFT + 8	Shift + 8	
9 VCR	SHIFT + 9	Shift + 9	
10/0 VCR	SHIFT + 0	Shift + 0	
11/+ VCR	SHIFT + -/-- GUIDE	Shift + Guide	
12/- VCR	SHIFT + FAV PRE-CH	Shift + Pre Ch	
Memo/CH/PGM	SHIFT + SETTINGS OPT	Shift + Options	
AMS/'/'' VCR	SHIFT + SOUND DUAL	Shift + Dual	
Mode VCR	SHIFT + AD SUBT	Shift + Subt	
>> VCR	SHIFT + >>	Shift + >>	
<< VCR	SHIFT + <<	Shift + <<	
Pause VCR	SHIFT + II	Shift + Pause	
Stop VCR	SHIFT + ■	Shift + Stop	
Rec VCR	SHIFT + REC MODE	Shift + Rec	
Play VCR	SHIFT + PLAY MODE ▶	Shift + Play	
<> VCR	SHIFT + >>I	Shift + >>I	

Original		Replacement	
UP	Volume UP CDV	+ VOL	Vol +
DOWN	Volume Down	VOL −	Vol -
MUTE	Mute CDV	MUTE	Mute
REAR	Rear	CLEAR EXIT	Exit
FRONT	Front	RETURN BACK	Back
L	L CDV	HOME SMART	Smart
R	R CDV	APP MEDIA	Media
1	1 CDV	1	1
2	2 CDV	2	2
3	3 CDV	3	3
4	4 CDV	4	4
5	5 CDV	5	5
6	6 CDV	6	6
7	7 CDV	7	7
8	8 CDV	8	8
9	9 CDV	9	9
10/0	10/0 CDV	0	0

Original		Replacement	
11/+	11/+ CDV	-/-- GUIDE	Guide
12/-	12/- CDV	FAV PRE-CH	Pre Ch
MEMO CH/PGM	Memo/CH/PGM	SETTINGS OPT	Options
MODE	Mode CDV	AD SUBT	Subt
▶	Play CDV	PLAY MODE ▶	Play
⏸	Pause CDV	⏸	Pause
■	Stop CDV	■	Stop
⏩	>> CDV	⏩	>>
⏪	<< CDV	⏪	<<
UP	Volume Up	SHIFT + + VOL	Shift + Vol +
DOWN	Volume Down	SHIFT + VOL −	Shift + Vol -
MUTE	Mute Tape	SHIFT + MUTE	Shift + Mute
L	L Tape	SHIFT + HOME SMART	Shift + Smart
R	R Tape	SHIFT + APP MEDIA	Shift + Media
1	1 Tape	SHIFT + 1	Shift + 1
2	2 Tape	SHIFT + 2	Shift + 2
3	3 Tape	SHIFT + 3	Shift + 3

Original	Replacement	Original	Replacement
4 Tape	SHIFT + 4 — Shift + 4	<< Tape	I <<
5 Tape	SHIFT + 5 — Shift + 5	Deck B Tape	SHIFT + B — Shift + Green
6 Tape	SHIFT + 6 — Shift + 6	Deck A Tape	SHIFT + A — Shift + Red
7 Tape	SHIFT + 7 — Shift + 7		
8 Tape	SHIFT + 8 — Shift + 8		
9 Tape	SHIFT + 9 — Shift + 9		
10/0 Tape	SHIFT + 0 — Shift + 0		
12/- Tape	SHIFT + FAV PRE-CH — Shift + Pre Ch		
11/+ Tape	SHIFT + -/-- GUIDE — Shift + Guide		
MEMO / CH/PGM	SHIFT + SETTINGS OPT — Shift + Options		
AMS/''/'' Tape	SOUND DUAL — Dual		
Play Tape	SHIFT + PLAY MODE ▶ — Shift + Play		
Pause Tape	SHIFT + ⏸ — Shift + Pause		
<> Tape	SHIFT + ⏭ — Shift + >>I		
Stop Tape	SHIFT + ■ — Shift + Stop		
>> Tape	SHIFT + ⏩ — Shift + >>		
Rec Tape	SHIFT + REC MODE ● — Shift + Rec		