Mandis shop

RC-393

Original		Replacement	
COUNTER CLEAR	Counter Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
DISPLAY	Display	MEDIA DISPLAY	Display / Media
AUTO MONITOR	Auto Monitor	LANG I/II AUDIO	Audio / Lang I/II
RECORD	Record	REC MODE	Rec / Rec Mode
REC MUTE	Rec Mute	DIMMER MUTE	Mute / Dimmer
PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze
<<	<<	TUNE-	<< / Tune-
>>	>>	TUNE+	>> / Tune+
STOP	Stop	HOLD	Stop / Hold
PLAY	Play	SLOW	Play / Slow

Original	Replacement

https://mandos-a-distancia.es/en/Teac/1063866-93176-replacement-remote-control-for-Teac-RC-393.html