Original		Replacement	
	On / Standby		Power
	Input Selector V		1
	Input Selector V		2
	Input Selector V		3
	Input Selector Multi CH		5
	Input Selector		6
	Input Selector		7
	Input Selector Tuner		8
	Input Selector C		9
	Dimmer		0
	Sleep		Sleep / Timer
	Guide/Top		Menu / Home
	Muting		Mute / Dimmer
	Return		Back / Return
	Setup		Eject / Surround
	Enter		OK
	Up		Up

Original		Replacement	
	Down		Down
	Right		Right
	Left		Left
	Play		Play / Slow
	Rev. Play		Pause / Step / Freeze
	Stop		Stop / Hold
	<<		>> / Tune+
	>>		I<< / Preset-
	I<<		<< / Tune-
	>>I		>>I / Preset+
	Listening Mode Stereo		Red / Netflix / Search
	Listening Mode Surround		Green / APP / Repeat
	Listening Mode <		Yellow / YouTube / Repeat
	Listening Mode >		Blue / Prime Video / Random
	Test Tone/Audi		Audio / Lang I/II
	CH Sel/Subtitl		Subtitle / EQ
	Level -/Random		TV/Radio / Program

Original		Replacement	
REPEAT LEVEL+	Level +/ Repeat	SIZE ZOOM	Zoom / Size
DISPLAY	Display	ANGLE INFO	Info / Angle
L.NIGHT DVD	L. Night	LIST SMART	Smart / List
CINE FLTR HDD	Cine FLTR	MEDIA DISPLAY	Display / Media
INPUT	Input Tv	SHIFT + RDS AV INPUT	Shift + AV / Input / RDS
CH DISC ALBUM +	CH/ Disc/ Album	CH PAGE +	CH+ / Page+
CH DISC ALBUM -	CH/ Disc/ Album-	CH PAGE -	CH- / Page-
VOL +	Vol +	VOL +	Vol +
VOL -	Vol -	VOL -	Vol -
Power	Power Tv/ Standby	SHIFT +	Shift + Power
VOL +	Vol + Tv	SHIFT + VOL +	Shift + Vol +
VOL -	Vol - Tv	SHIFT + VOL -	Shift + Vol -
1	1 Tv	SHIFT + TV 1	Shift + 1
2	2 Tv	SHIFT + DVD 2	Shift + 2
3	3 Tv	SHIFT + CD-STB 3	Shift + 3
4	4 Tv	SHIFT + VIDEO 4	Shift + 4
5 MULTI CH	5 Tv	SHIFT + TAPE 5	Shift + 5

Original		Replacement	
6 DVD	6 Tv	SHIFT + TUNER 6	Shift + 6
7 TAPE	7 Tv	SHIFT + AUX-HDD 7	Shift + 7
8 TUNER	8 Tv	SHIFT + USB 8	Shift + 8
9 CD	9 Tv	SHIFT + BLUETOOTH 9	Shift + 9
0 DIMMER	0 Tv	SHIFT + HDMI-SAT 0	Shift + 0
+10	+10 Tv	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--
PREVIOUS MENU MUTING	Muting/ Previous Menu Tv	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer
ENTER	Enter Tv	SHIFT + OK	Shift + OK
PLAYLIST/CAT+	Right Tv	SHIFT +	Shift + Right
PLAYLIST/CAT-	Left Tv	SHIFT +	Shift + Left
SETUP	Setup Tv	TOP MENU D.MENU	D. Menu / Top
	Up Tv	SHIFT +	Shift + Up
	Down Tv	SHIFT +	Shift + Down

Original		Replacement	
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	VCR		Shift + 4
	+10/ 10/ -/ --		Guide / EPG / -/--
	0/ 11		0
	CLR		Exit / Cancel / Clear
	Top Menu		D. Menu / Top
	Up		Up
	Previous Menu/ Muting		Menu / Home

Original		Replacement	
	Previous Menu/ Muting		Mute / Dimmer
	Left/ Playlist/ Ca		Left
	Enter		OK
	Right/ Playlist/ C		Right
	Return		Back / Return
	Down		Down
	Setup		Setup / OPT /
	Pause		Pause / Step / Freeze
	Play		Play / Slow
	Stop		Stop / Hold
	<<		<< / Tune-
	>>		>> / Tune+
	I <<		I << / Preset-
	>>I		>>I / Preset+
	Stereo		Sound / Title
	Surround		Eject / Surround
	< Listening Mode		Shift + I << / Preset-

Original	Replacement	Original	Replacement
Listening Mode >	SHIFT + PRESET+ (Shift + >>I / Preset+)		
Audio	LANG I/II AUDIO (Audio / Lang I/II)		
Subtitle	EQ SUBTITLE (Subtitle / EQ)		
Random	Prime Video RANDOM (Blue / Prime Video / Random)		
Repeat	APP REPEAT (Green / APP / Repeat)		
Display	MEDIA DISPLAY (Display / Media)		
Play Mode VCR	FORMAT PICTURE (Picture / Format)		
DVD	SHIFT + DVD 2 (Shift + 2)		
HDD	SHIFT + AUX-HDD 7 (Shift + 7)		

Original		Replacement	
ON/STANDBY	On / Standby		Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
+10	+10/10/-/--	GUIDE EPG	Guide / EPG / -/--
0	0/11	HDMI-SAT 0	0
CLR	12	PC FAV MARKER	Fav / Marker / PC
CH DISC ALBUM +	Disc+	CH PAGE +	CH+ / Page+
VOL +	Vol +	VOL +	Vol +
CH DISC ALBUM -	Disc-	CH PAGE -	CH- / Page-
VOL -	Vol -	VOL -	Vol -

Original		Replacement	
Pause		STEP-FREEZE	Pause / Step / Freeze
Play		SLOW	Play / Slow
Stop		HOLD	Stop / Hold
<<		TUNE-	<< / Tune-
>>		TUNE+	>> / Tune+
I<<		PRESET-	I<< / Preset-
>>I		PRESET+	>>I / Preset+
Stereo		LANG I/II AUDIO	Audio / Lang I/II
Surround		SURROUND	Eject / Surround
< Listening Mode		SHIFT + PRESET-	Shift + I<< / Preset-
Listening Mode >		SHIFT + PRESET+	Shift + >>I / Preset+
RANDOM LEVEL-	Random	Prime Video RANDOM	Blue / Prime Video / Random
REPEAT LEVEL+	Repeat	APP REPEAT	Green / APP / Repeat
DISPLAY	Display	MEDIA DISPLAY	Display / Media

Original		Replacement	
ON/STANDBY	Power		Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
+10	+10/ 10/ -/ - -	-/-- GUIDE EPG	Guide / EPG / -/ - -
0 DIMMER	0/ 11	HDMI - SAT 0	0
CH DISC ALBUM +	CH+	CH PAGE +	CH+ / Page+
CH DISC ALBUM -	CH-	CH PAGE -	CH- / Page-
	Pause	STEP - FREEZE	Pause / Step / Freeze
	Play	SLOW	Play / Slow
	Stop	HOLD	Stop / Hold

Original		Replacement	
<<	<<	TUNE-	<< / Tune-
STEREO	Stereo	LANG I/II AUDIO	Audio / Lang I/II
SURROUND	Surround	SURROUND	Eject / Surround
	< Listening Mode	SHIFT + PRESET-	Shift + I<< / Preset-
	Listening Mode >	SHIFT + PRESET+	Shift + >>I / Preset+
PLAY MODE VCR	Play Mode	TOP MENU D.MENU	D.Menu / Top
L NIGHT DVD	L. Night	TIMER SLEEP	Sleep / Timer