Original		Replacement	
POWER	Power		Power
MUTE	Mute	MUTE	Mute
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
FAV	FAV	SHIFT + FAV PRE-CH	Shift + Pre Ch
	Recall	FAV PRE-CH	Pre Ch
GAME	Game	APP MEDIA	Media
AUTO	Auto	HOME SMART	Smart
INFO	Info	DISPLAY INFO	Info

Original		Replacement	
MENU	Menu	TOP MENU MENU	Menu
EPG	EPG	-/-- GUIDE	Guide
EXIT	Exit	CLEAR EXIT	Exit
CH+	Up / CH + / I<		Up
CH-	Down / CH - / >>		Down
V+	Right / Vol +		Right
V-	Left / Vol -		Left
OK	OK	OK	Ok
CH+	Up / CH + / I<		I<<
CH-	Down / CH - / >>		>>I
CH+	Up / CH + / I<	+ CH	Ch +
CH-	Down / CH - / >>	CH -	Ch -
V-	Left / Vol -	VOL -	Vol -
V+	Right / Vol +	+ VOL	Vol +
ZOOM	Red / Zoom	A	Red
LAN/AUDIO	Green / Lan/Audi	B	Green
PLAY/PAUSE	Yellow / Play/Pause	C	Yellow

Original		Replacement		Original	Replacement
TEXT	Blue / Text	D	Blue		
ZOOM	Red / Zoom	ZOOM ⏏	Eject		
LAN/AUDIO	Green / Lan/ Audi	SOUND DUAL	Dual		
PLAY/PAUSE	Yellow /	PLAY MODE ▶	Play		
PLAY/PAUSE	Yellow /	⏸	Pause		
TEXT	Blue / Text	REPEAT TEXT	Text		
TV/RADIO ◀◀	<< / Tv/ Radio	◀◀	<<		
TV/RADIO ◀◀	<< / Tv/ Radio	SEARCH TV/R	TV/R		
SUBTITLE ▶▶	>> / Subtitle	▶▶	>>		
SUBTITLE ▶▶	>> / Subtitle	AD SUBT	Subt		