Original		Replacement	
STANDBY	Standby		Power
DTV/VCR	DTV/ VCR	TIMER AV	AV
REC LIST	Rec List	DISC NAV LIST	List
SLOW	Slow	APP MEDIA	Media
	Play	PLAY MODE	Play
PAUSE	Pause		Pause
	Stop		Stop
	>>		>>
	<<		<<
RECORD	Record	REC MODE	Rec
MENU	Menu	TOP MENU MENU	Menu
EXIT	Exit	CLEAR EXIT	Exit
EPG	EPG	-/-- GUIDE	Guide
FAVORITE	Favorite	FAV PRE-CH	Pre Ch
CH+	Up		Up
CH-	Down		Down
VOL+	Right		Right

Original		Replacement	
VOL-	Left		Left
OK	OK	OK	Ok
CH+	CH+	+ CH	Ch +
CH-	CH-	CH -	Ch -
VOL+	Vol +	+ VOL	Vol +
VOL-	Vol -	VOL -	Vol -
GOTO	Goto	SETTINGS OPT	Options
RECALL	Recall	RETURN BACK	Back
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9

Original		Replacement		Original	Replacement
0	0	0	0		
PVR INFO	PVR Info	PICTURE FORMAT	Format		
INFO	Info	DISPLAY INFO	Info		
SUBTITLE	Subtitle	AD SUBT	Subt		
TEXT	Text	REPEAT TEXT	Text		
TV/RADIO	Tv/Radio	SEARCH TV/R	TV/R		
LANG	Lang	SOUND DUAL	Dual		
AUDIO	Audio	SHIFT + SOUND DUAL	Shift + Dual		
MUTE	Mute	MUTE	Mute		
	Red	A	Red		
	Green	B	Green		
	Yellow	C	Yellow		
	Blue	D	Blue		