Original		Replacement	
	RCVR Sleep		Sleep / Timer
	RCVR On		Power
	RCVR Standby	SHIFT +	Shift + Power
	RCVR Return		Back / Return
	RCVR Setup		Setup / OPT /
	RCVR Disc+		CH+ / Page+
	RCVR Up		Up
	RCVR Vol +		Vol +
	RCVR Disc-		CH- / Page-
	RCVR Left		Left
	RCVR Enter		OK
	RCVR Right		Right
	RCVR Vol -		Vol -
	RCVR Down		Down
	RCVR Audio		Audio / Lang I/II
	RCVR CH Sel / Top Menu		D.Menu / Top
	RCVR Test / Menu		Menu / Home

Original		Replacement	
	RCVR Muting		Mute / Dimmer
	RCVR Level	SHIFT +	Shift + Down
	RCVR Level Up	SHIFT +	Shift + Up
	RCVR I<<		I<< / Preset-
	RCVR Play		Play / Slow
	RCVR >>I		>>I / Preset+
	RCVR <<		<< / Tune-
	RCVR Stop		Stop / Hold
	RCVR >>		>> / Tune+
	RCVR Rec /		Blue / Prime Video / Random
	RCVR Pause / Play Rev.		Pause / Step / Freeze
	Open / Close		Eject / Surround
	RCVR Input Sel.		2
	RCVR Input Sel.		3
	RCVR Input Sel.		4
	RCVR Input Sel.		1
	RCVR Input Sel.		5

Original		Replacement	
TUN	RCVR Input Sel.	TUNER 6	6
V3	RCVR Input Sel.	AUX - HDD 7	7
V4	RCVR Input Sel.	USB 8	8
V5	RCVR Input Sel.	BLUETOOTH 9	9
PH	RCVR Input Sel.	HDMI - SAT 0	0
1 STEREO	RCVR Stereo	SHIFT + TV 1	Shift + 1
2 DIRECT	RCVR Direct	SHIFT + DVD 2	Shift + 2
3 DSP ►	RCVR DSP ►	SHIFT + CD - STB 3	Shift + 3
4 SURR	RCVR SURR	SHIFT + VIDEO 4	Shift + 4
4 SURR	RCVR SURR	SHIFT + SURROUND ⏏	Shift + Eject / Surround
5 THX	RCVR THX	SHIFT + TAPE 5	Shift + 5
6 DSP ◄	RCVR ◄ DSP	SHIFT + TUNER 6	Shift + 6
7 SP A	RCVR SP A	SHIFT + AUX - HDD 7	Shift + 7
8 SP B	RCVR SP B	SHIFT + USB 8	Shift + 8
9 Re-EQ	RCVR Re-EQ	EQ SUBTITLE	Subtitle / EQ
9 Re-EQ	RCVR Re-EQ	SHIFT + BLUETOOTH 9	Shift + 9
+10 DISPLAY	RCVR Display	MEDIA DISPLAY	Display / Media

Original		Replacement	
0 DIMMER	RCVR Dimmer	SHIFT + HDMI - SAT 0	Shift + 0
0 DIMMER	RCVR Dimmer	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer
SEARCH ZONE 2 ENTER	RCVR Zone 2	LIST SMART	Smart / List

Original		Replacement	
ON	ON	Power	
STDBY	STDBY	SHIFT + Power	
Return	RETURN	BACK / Return	
Setup	SETUP	OPT-TOOLS / SETUP	Setup / OPT /
Disc+	CH DISC	CH+ / Page+	
Up		Up	
Vol +	VOL	Vol +	
Disc-	CH DISC	CH- / Page-	
Left		Left	
Enter	ENTER	OK	
Right		Right	
Vol -	VOL	Vol -	
Down		Down	
Top Menu	CH SEL TOP MENU	TOP MENU / D.MENU	D.Menu / Top
Menu	TEST MENU	HOME / MENU	Menu / Home
Muting	MUTING	DIMMER / MUTE	Mute / Dimmer
Angle	ANGLE	ANGLE / INFO	Info / Angle

Original		Replacement	
Subtitle	SUBTITLE / LEVEL	EQ / SUBTITLE	Subtitle / EQ
I<<		PRESET-	I<< / Preset-
Play		SLOW	Play / Slow
>>I		PRESET+	>>I / Preset+
<<		TUNE-	<< / Tune-
Stop		HOLD	Stop / Hold
>>		TUNE+	>> / Tune+
Random	RANDOM	Prime Video / RANDOM	Blue / Prime Video / Random
Pause		STEP-FREEZE	Pause / Step / Freeze
Open / Close	OPEN/CLOSE	SURROUND	Eject / Surround
1	1 STEREO	TV 1	1
2	2 DIRECT	DVD 2	2
3	3 DSP	CD-STB 3	3
4	4 SURR	VIDEO 4	4
5	5 THX	TAPE 5	5
6	6 DSP	TUNER 6	6
7	7 SP A	AUX-HDD 7	7

Original		Replacement		Original		Replacement	
8 SP B	8	USB 8	8				
9 Re-EQ	9	BLUETOOTH 9	9				
+10 DISPLAY	+10	-/-- GUIDE EPG	Guide / EPG / -/--				
0 DIMMER	0	HDMI - SAT 0	0				
SEARCH ZONE 2 ENTER	Search	NETFLIX SEARCH	Red / Netflix / Search				

Original		Replacement		Original		Replacement	
ON	ON	Power	Power	3	3	3	3
STDBY	STDBY	Shift + Power	SHIFT + Power	4	4	4	4
Disc+	CH DISC	CH+ / Page+	CH PAGE	5	5	5	5
Vol +	VOL	Vol +	VOL	6	6	6	6
Vol -	VOL	Vol -	VOL	7	7	7	7
Muting	MUTING	Mute / Dimmer	DIMMER MUTE	8	8	8	8
I<<		I<< / Preset-	PRESET-	9	9	9	9
Play		Play / Slow	SLOW	+10	+10	Guide / EPG / -/--	GUIDE EPG
>>I		>>I / Preset+	PRESET+	0	0	0	0
<<		<< / Tune-	TUNE-				
Stop		Stop / Hold	HOLD				
>>		>> / Tune+	TUNE+				
Random	RANDOM	Blue / Prime Video / Random	Prime Video RANDOM				
Pause		Pause / Step / Freeze	STEP-FREEZE				
	OPEN/CLOSE	Eject / Surround	SURROUND				
1	1 STEREO	1	TV 1				
2	2 DIRECT	2	DVD 2				

Original		Replacement		Original		Replacement	
ON	ON	Power	Power	1	1	1	1
STDBY	STDBY	SHIFT + Power	Shift + Power	2	2	2	2
Vol +	VOL	Vol +	Vol +	3	3	3	3
Enter	ENTER	OK	OK	4	4	4	4
Enter	ENTER	FAV MARKER	Fav / Marker / PC	5	5	5	5
Vol -	VOL	VOL	Vol -	6	6	6	6
Muting	MUTING	DIMMER MUTE	Mute / Dimmer	7	7	7	7
I<<		PRESET-	I<< / Preset-	8	8	8	8
Play		SLOW	Play / Slow	9	9	9	9
>>I		PRESET+	>>I / Preset+	+10	+10	GUIDE EPG	Guide / EPG / -/--
<<		TUNE-	<< / Tune-	0	0	0	0
Stop		HOLD	Stop / Hold				
>>		TUNE+	>> / Tune+				
Rec / Random	RANDOM	Prime Video	Blue / Prime Video / Random				
Rec / Random	RANDOM	REC MODE	Rec / Rec Mode				
Pause		STEP-FREEZE	Pause / Step / Freeze				
Open / Close	OPEN/CLOSE	SURROUND	Eject / Surround				