Original		Sustituto	
Open/Close	OPEN/ CLOSE	Eject / Surround	SURROUND
Sound Mode	SOUND MODE	Sound / Title	TITLE SOUND
Display	DISPLAY	Display / Media	MEDIA DISPLAY
Time	TIME	Sleep / Timer	TIMER SLEEP
Text	TEXT	Text / Goto	GOTO TEXT
Menu	MENU	Menu / Home	HOME MENU
Enter	ENTER	OK	OK
Recall Scroll	RECALL SCROLL	Back / Return	RETURN BACK
Input Up	INPUT	CH+ / Page+	CH PAGE +
Vol +	VOLUME	Vol +	VOL +
Input Down	INPUT	CH- / Page-	CH PAGE −
Vol -	VOLUME	Vol -	VOL −
Pause	⏸	Pause / Step / Freeze	STEP-FREEZE ⏸
I<<	⏮	I<< / Preset-	PRESET- ⏮
Play	▶	Play / Slow	SLOW ▶
>>I	⏭	>>I / Preset+	PRESET+ ⏭
Stop	■	Stop / Hold	HOLD ■

Original		Sustituto	
<<	◀◀	<< / Tune-	TUNE- ◀◀
>>	▶▶	>> / Tune+	TUNE+ ▶▶
Quick Replay	QUICK REPLAY	Smart / List	LIST SMART
AMS	AMS	Red / Netflix / Search	NETFLIX SEARCH
A-B	A-B	Yellow / YouTube / Repeat	YouTube REPEAT A-B
Repeat	REPEAT	Green / APP / Repeat	APP REPEAT
Prog	PROG.	TV/Radio /	PROGRAM TV/ RADIO
Cancel	CANCEL	Exit / Cancel / Clear	CLEAR EXIT CANCEL
Random	RANDOM	Blue / Prime Video / Random	Prime Video RANDOM
1	1	1	TV 1
2	2	2	DVD 2
3	3	3	CD - STB 3
4	4	4	VIDEO 4
5	5	5	TAPE 5
6	6	6	TUNER 6
7	7	7	AUX - HDD 7
8	8	8	USB 8

Original		Sustituto		Original	Sustituto
9	9	BLUETOOTH 9	9		
0	0	HDMI - SAT 0	0		
NOISE SHAPER	Noise Shaper	LANG I/II AUDIO	Audio / Lang I/II		
DC FILTER	DC Filter	EQ SUBTITLE	Subtitle / EQ		
FILTER	Filter	ANGLE INFO	Info / Angle		
DIGITAL OUT OFF	Digital Out Of	DIMMER MUTE	Mute / Dimmer		