Original		Sustituto		Original		Sustituto	
STANDBY	Power		Power	CH+	Up / CH +	CH PAGE +	CH+ / Page+
OPEN/CLOSE	Open / Close	SURROUND	Eject / Surround	CH+	Up / CH +		Up
1	1	TV 1	1	REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
2	2	DVD 2	2	SEEK-	Left / Seek -		Left
3	3	CD - STB 3	3	⏯	Play / Pause	SLOW	Play / Slow
4	4	VIDEO 4	4	⏯	Play / Pause	STEP - FREEZE	Pause / Step / Freeze
5	5	TAPE 5	5	⏯	Play / Pause	OK	OK
6	6	TUNER 6	6	SEEK+	Right / Seek -		Right
7	7	AUX - HDD 7	7	⏪	<<	TUNE-	<< / Tune-
8	8	USB 8	8	CH-	Down / CH -		Down
9	9	BLUETOOTH 9	9	CH-	Down / CH -	CH PAGE -	CH- / Page-
0	0	HDMI - SAT 0	0	⏭	>>I	PRESET+	>>I / Preset+
10+	10+	-/-- GUIDE EPG	Guide / EPG / -/--	⏩	>>	TUNE+	>> / Tune+
EQ	EQ	EQ SUBTITLE	Subtitle / EQ	⏹	Stop	HOLD	Stop / Hold
MUTE	Mute	DIMMER MUTE	Mute / Dimmer	I⏮	I<<	PRESET-	I<< / Preset-
PROG	Prog	PROGRAM TV/RADIO	TV/Radio /	CD/FM	CD / FM	RDS AV INPUT	AV / Input / RDS
RANDOM	Random	Prime Video RANDOM	Blue / Prime Video / Random	CD/USB	CD / USB	SHIFT + CD - STB 3	Shift + 3

Original		Sustituto		Original		Sustituto
BASS	Bass	LANG I/II AUDIO	Audio / Lang I/II			
AUTO	Auto	ANGLE INFO	Info / Angle			
SAVE	Save	MEDIA DISPLAY	Display / Media			
VOL-	Vol -	VOL −	Vol -			
TREBLE	Treble	FORMAT PICTURE	Picture / Format			
PREVIEW	Preview	PC FAV MARKER	Fav / Marker / PC			
ST/MO	ST / MO	TITLE SOUND	Sound / Title			
VOL+	Vol +	+ VOL	Vol +			