Mandis shop

Yamaha VR09400

Original		Sustituto	
POWER	Power		Power
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
PLAY/CUT	Play/Cut	MEDIA DISPLAY	Display / Media
PHONO	Phono	DVD 2	2
SKI	I<< CD	PRESET-	I<< / Preset-
SKIP	>>I CD	PRESET+	>>I / Preset+
PLAY	Play CD	SLOW	Play / Slow
CD	CD	CD-STB 3	3
SEAR	<< CD	TUNE-	<< / Tune-
EARCH	>> CD	TUNE+	>> / Tune+
PAUSE/STOP	Pause CD	STEP-FREEZE	Pause / Step / Freeze
PAUSE/STOP	Stop CD	HOLD	Stop / Hold
DISC SKIP	Disc Skip CD	SURROUND	Eject / Surround
PRES	Preset- Tuner	SHIFT + PRESET-	Shift + I<< / Preset-
PRES	Preset- Tuner	CH PAGE -	CH- / Page-
RESET +	Preset+ Tuner	SHIFT + PRESET+	Shift + >>I / Preset+
RESET +	Preset+ Tuner	CH PAGE +	CH+ / Page+

Original		Sustituto	
A/B/C/D/E	A/B/C/D/E Tuner	LIST SMART	Smart / List
TUNER	Tuner	TUNER 6	6
DIR A	Dir A Tape		Left
DECK A/B	Deck A/B Tape	OK	OK
DIR B	Dir B Tape		Right
TAPE 1	Tape 1	TAPE 5	5
	<< Tape	SHIFT + TUNE-	Shift + << /
PLAY	Play Tape	SHIFT + SLOW	Shift + Play /
	>> Tape	SHIFT + TUNE+	Shift + >> /
TAPE 2	Tape 2	VIDEO 4	4
REC/PAUSE	Rec/Pause Tape	SHIFT + STEP-FREEZE	Shift + Pause / Step /
STOP	Stop Tape	SHIFT + HOLD	Shift + Stop /
REC MUTE	Rec Mute	DIMMER MUTE	Mute / Dimmer
AUX	AUX	AUX-HDD 7	7
-	Vol -	VOL -	Vol -
+	Vol +	VOL +	Vol +

https://mandis.es/es/Yamaha/1035687-mando-sustitucion-para-Yamaha-VR09400.htm