Original		Sustituto	
	Power		Power
	1		1
	2		2
	3		3
	PIP		Info / Angle
	4		4
	5		5
	6		6
	[<>]		Picture / Format
	>I		>>I / Preset+
	7		7
	8		8
	9		9
	?		Smart / List
	I<		I<< / Preset-
	0		0
	Mute		Mute / Dimmer

Original		Sustituto	
	i / OSD		Display / Media
	Z / Disc Menu		Menu / Home
	Up		Up
	P+		CH+ / Page+
	Left		Left
	Vol -		Vol -
	OK		OK
	Right		Right
	Vol +		Vol +
	TXT		Text / Goto
	<<		<< / Tune-
	Down		Down
	P-		CH- / Page-
	TV-G		Guide / EPG / -/--
	>>		>> / Tune+
	Red / Image / I>		Red / Netflix / Search
	Green / Timer		Green / APP / Repeat

Original		Sustituto		Original		Sustituto	
	Play	SLOW	Play / Slow				
	Yellow/Pause	YouTube REPEAT A-B	Yellow / YouTube / Repeat				
	Pause	STEP-FREEZE	Pause / Step / Freeze				
	Blue/Sound	Prime Video RANDOM	Blue / Prime Video / Random				
	Stop	HOLD	Stop / Hold				
	Blue/Sound	TITLE SOUND	Sound / Title				

Original		Sustituto	
	Power		Power
	1		1
ABC	2		2
DEF	3		3
Audio	Audio		Audio / Lang I/II
GHI	4		4
JKL	5		5
MNO	6		6
	[<>]		Zoom / Size
	>I		>>I / Preset+
PQRS	7		7
TUV	8		8
WXYZ	9		9
	?		Smart / List
	I<		I<< / Preset-
	0		0
OSD	i / OSD		Display / Media

Original		Sustituto	
Disc Menu	Disc Menu		D.Menu / Top
Disc Menu	Disc Menu		Menu / Home
	Up		Up
	P+		CH+ / Page+
	Left		Left
	Vol -		Vol -
OK	OK	OK	OK
	Right		Right
	Vol +		Vol +
	TXT		Text / Goto
	<<		<< / Tune-
	Down		Down
	P-		CH- / Page-
TV-G	TV-G		Guide / EPG / -/--
TV-G	>>		>> / Tune+
	Red/Picture		Picture / Format
	Red/Picture		Red / Netflix / Search

Original	Sustituto	Original	Sustituto
Green / Timer	Sleep / Timer		
Play	Play / Slow		
Green / Timer	Green / APP / Repeat		
Yellow/Pause	Yellow / YouTube / Repeat		
Pause	Pause / Step / Freeze		
Blue/Sound	Sound / Title		
Stop	Stop / Hold		
Blue/Sound	Blue / Prime Video / Random		

Original		Sustituto	
	Power		Power
	1		1
	2		2
	3		3
	Audio		Audio / Lang I/II
	4		4
	5		5
	6		6
	[<>]		Zoom / Size
	>I		>>I / Preset+
	7		7
	8		8
	9		9
	?		Smart / List
	I<		I<< / Preset-
	0		0
	Mute		Mute / Dimmer

Original		Sustituto	
	i / OSD		Display / Media
	Z / Disc Menu		Menu / Home
	Up		Up
	P+		CH+ / Page+
	Left		Left
	Vol -		Vol -
	OK		OK
	Right		Right
	Vol +		Vol +
	TXT		Text / Goto
	<<		<< / Tune-
	Down		Down
	P-		CH- / Page-
	TV-G		Guide / EPG / -/--
	>>		>> / Tune+
	Red / Image / I>		Red / Netflix / Search
	Red / Image / I>		Shift + Play / Slow

Original	Sustituto	Original	Sustituto
Green/Timer	Green / APP / Repeat		
Play	Play / Slow		
Green/Timer	Sleep / Timer		
Pause	Pause / Step / Freeze		
Yellow/Pause	Yellow / YouTube / Repeat		
Blue/Sound	Blue / Prime Video / Random		
Stop	Stop / Hold		
Blue/Sound	Sound / Title		

Original		Sustituto	
	Power		Power
	1		1
	2		2
	3		3
	PIP/Audio		Audio / Lang I/II
	4		4
	5		5
	6		6
	[<>]		Zoom / Size
	>I		>>I / Preset+
	7		7
	8		8
	9		9
	?		Smart / List
	I<		I<< / Preset-
	0		0
	i/OSD		Display / Media

Original		Sustituto	
	Z/Disc Menu		Menu / Home
	P+		CH+ / Page+
	Up		Up
	Left		Left
	Vol -		Vol -
	OK		OK
	Right		Right
	Vol +		Vol +
	TXT		Text / Goto
	<<		<< / Tune-
	P-		CH- / Page-
	Down		Down
	TV-G		Guide / EPG / -/--
	>>		>> / Tune+
	Red/Image/I>		Picture / Format
	Red/Image/I>		Red / Netflix / Search
	Green/Timer		Green / APP / Repeat

Original	Sustituto	Original	Sustituto
Play	Play / Slow		
Green/Timer	Sleep / Timer		
Yellow/Pause	Yellow / YouTube / Repeat		
Pause	Pause / Step / Freeze		
Blue/Sound	Blue / Prime Video / Random		
Stop	Stop / Hold		
Blue/Sound	Sound / Title		