Original		Sustituto	
	Power		Power
PROG	Prog+	CH PAGE +	CH+ / Page+
	Prog-	CH PAGE −	CH- / Page-
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
TV/VTR	Tv/ VTR	PROGRAM TV/ RADIO	TV/ Radi o /
VOL +	Vol +	VOL +	Vol +
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
DATA SCREEN	Data Screen	MEDIA DISPLAY	Di spl ay / Medi a
VOL −	Vol -	VOL −	Vol -
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
-/--	- / - -	-/-- GUIDE EPG	Gui de / EPG / - / - -

Original		Sustituto	
0	0	HDMI - SAT 0	0

Original	Sustituto	Original	Sustituto
Check	Smart / List	Input Select	AV / Input / RDS
Clear	Exit / Cancel / Clear	Vol -	Vol -
On/Off Timer/Rec	Sleep / Timer	7	7
Power	Power	8	8
Prog+	CH+ / Page+	9	9
Prog-	CH- / Page-	Timer On	Green / APP / Repeat
Transmit	Red / Netflix / Search	Counter Reset	Yellow / YouTube / Repeat
1	1	Index	Info / Angle
2	2	-/--	Guide / EPG / -/--
3	3	0	0
Rec Mode	Shift + Rec / Rec Mode	Up	Up
Tv/VTR	TV/Radio /	PinP	Picture / Format
Vol +	Vol +	Shift	Text / Goto
4	4	Digital Off	Zoom / Size
5	5	Menu	Menu / Home
6	6	Left	Left
Data Screen	Display / Media	Execute	OK

Original		Sustituto		Original		Sustituto	
	Right		Right	FF	>>/ FF	TUNE+	>> / Tune+
EDIT MONITOR	Edit Monitor	EQ SUBTITLE	Subtitle / EQ	SEARCH	Search >>	PRESET+	>>I / Preset+
INDEX MARK	Index Mark	OPT-TOOLS SETUP	Setup / OPT /	STOP	Stop	HOLD	Stop / Hold
INDEX ERASE	Index Erase	PC FAV MARKER	Fav / Marker / PC				
	Down		Down				
	< Frame	SHIFT	+ Shift + Left				
FRAME	>I < Frame	SHIFT	+ OK Shift + OK				
	Frame >	SHIFT	+ Shift + Right				
PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze				
REC	Rec	REC MODE	Rec / Rec Mode				
SLOW-	Slow-	SHIFT	+ CH PAGE Shift + CH- /				
SLOW+	Slow+	SHIFT	+ CH PAGE Shift + CH+ /				
AUDIO DUB	Audio Dub	LANG I/II AUDIO	Audio / Lang I/II				
PLAY	Play	SLOW	Play / Slow				
HIGH SPEED REWIND	<<< High Speed Remain	RETURN BACK	Back / Return				
SEARCH	<< Search	PRESET-	I<< / Preset-				
REW	<</ REW	TUNE-	<< / Tune-				

Original	Sustituto	Original	Sustituto
Check	Smart / List	Input Select	AV / Input / RDS
Clear	Exit / Cancel / Clear	Vol -	Vol -
On/Off Timer Rec	Sleep / Timer	7	7
Power	Power	8	8
Prog+	CH+ / Page+	9	9
Prog-	CH- / Page-	Timer On	Green / APP / Repeat
Transmit	Red / Netflix / Search	Counter Reset	Yellow / YouTube / Repeat
1	1	Index	Info / Angle
2	2	-/--	Guide / EPG / -/--
3	3	0	0
Rec Mode	Shift + Rec / Rec Mode	Up	Up
Tv/VTR	TV/Radio /	PinP	Picture / Format
Vol +	Vol +	Shift	Text / Goto
4	4	Digital Off	Zoom / Size
5	5	Menu	Menu / Home
6	6	Left	Left
Data Screen	Display / Media	Execute	OK

Original		Sustituto	
	Right		Right
EDIT MONITOR	Edit Monitor	EQ SUBTITLE	Subtitle / EQ
INDEX MARK	Index Mark	OPT-TOOLS SETUP	Setup / OPT /
INDEX ERASE	Index Erase	PC FAV MARKER	Fav / Marker / PC
	Down		Down
	< Frame	SHIFT +	Shift + Left
FRAME	>I < Frame	SHIFT + OK	Shift + OK
	Frame >	SHIFT +	Shift + Right
PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze
REC	Rec	REC MODE	Rec / Rec Mode
SLOW -	Slow-	SHIFT + CH PAGE -	Shift + CH- /
SLOW +	Slow+	SHIFT + CH PAGE +	Shift + CH+ /
AUDIO DUB	Audio Hub	LANG I/II AUDIO	Audio / Lang I/II
PLAY	Play	SLOW	Play / Slow
HIGH SPEED REWIND	<<< High Speed Remain	RETURN BACK	Back / Return
SEARCH	<< search	PRESET-	I<< / Preset-
REW	<</REW	TUNE-	<< / Tune-

Original		Sustituto	
FF	>>/FF	TUNE+	>> / Tune+
SEARCH	Search >>	PRESET+	>>I / Preset+
STOP	Stop	HOLD	Stop / Hold

Original	Sustituto	Original	Sustituto
Check	Smart / List	Input Select	AV / Input / RDS
Clear	Exit / Cancel / Clear	Vol -	Vol -
On/Off Timer Rec	Sleep / Timer	7	7
Power	Power	8	8
Prog+	CH+ / Page+	9	9
Prog-	CH- / Page-	Timer On	Green / APP / Repeat
Transmit	Red / Netflix / Search	Counter Reset	Yellow / YouTube / Repeat
1	1	Index	Info / Angle
2	2	-/--	Guide / EPG / -/--
3	3	0	0
Rec Mode	Shift + Rec / Rec Mode	Up	Up
Tv/VTR	TV/Radio /	PinP	Picture / Format
Vol +	Vol +	Shift	Text / Goto
4	4	Digital Off	Zoom / Size
5	5	Menu	Menu / Home
6	6	Left	Left
Data Screen	Display / Media	Execute	OK

Original	Sustituto	Original	Sustituto
Right	Right	>>/ FF	>> / Tune+
Edit Monitor	Subtitle / EQ	Search >>	>>I / Preset+
Index Mark	Setup / OPT /	Stop	Stop / Hold
Index Erase	Fav / Marker / PC		
Down	Down		
< Frame	Shift + Left		
>I < Frame	Shift + OK		
Frame >	Shift + Right		
Pause	Pause / Step / Freeze		
Rec	Rec / Rec Mode		
Slow-	Shift + CH- /		
Slow+	Shift + CH+ /		
Audio Dub	Audio / Lang I/II		
Play	Play / Slow		
<<</ High Speed Rewind	Back / Return		
<< Search	I<< / Preset-		
<</ REW	<< / Tune-		