Original		Sustituto		Original		Sustituto	
	Power		Power		Prog	PROGRAM TV/RADIO	TV/Radio /
	Open/Close	SURROUND	Eject / Surround		Setup	OPT-TOOLS SETUP	Setup / OPT /
1	1	TV 1	1		Up		Up
2	2	DVD 2	2	DVD/USB	DVD/USB	RDS AV INPUT	AV / Input / RDS
3	3	CD-STB 3	3	DVD/USB	DVD/USB	SHIFT + DVD 2	Shift + 2
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ	DVD/USB	DVD/USB	SHIFT + USB 8	Shift + 8
4	4	VIDEO 4	4		Left		Left
5	5	TAPE 5	5	ENTER	Enter	OK	OK
6	6	TUNER 6	6		Right		Right
LANGUAGE	Language	LANG I/II AUDIO	Audio / Lang I/II	MENU	Menu	HOME MENU	Menu / Home
7	7	AUX-HDD 7	7		Down		Down
8	8	USB 8	8	MUTE	Mute	DIMMER MUTE	Mute / Dimmer
9	9	BLUETOOTH 9	9		<</Rev	TUNE-	<< / Tune-
OSD	OSD	MEDIA DISPLAY	Display / Media		Stop	HOLD	Stop / Hold
0/10	0/10	HDMI-SAT 0	0		Play / Pause	SLOW	Play / Slow
10+	10+	-/-- GUIDE EPG	Guide / EPG / -/--		Play / Pause	STEP-FREEZE	Pause / Step / Freeze
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear		I<</Prev	PRESET-	I<< / Preset-

Original		Sustituto	
SEARCH	Search	NETFLIX / SEARCH	Red / Netflix / Search
REPEAT	Repeat	APP / REPEAT	Green / APP / Repeat
▶▶	>> / Fwd	TUNE+ ▶▶	>> / Tune+
▶▶|	>>| / Next	PRESET+ ▶▶|	>>| / Preset+
–	Vol -	VOL –	Vol -
+	Vol +	+ VOL	Vol +
TITLE	Title	TITLE / SOUND	Sound / Title
RETURN	Return	RETURN / BACK	Back / Return
V-MODE	V-Mode	FORMAT / PICTURE	Picture / Format
SLOW	Slow	SHIFT + SLOW ▶	Shift + Play /
A-B	A-B	YouTube / REPEAT A-B	Yellow / YouTube / Repeat
RAN	RAN	GOTO / TEXT	Text / Goto
N/P	N/P	+ CH PAGE	CH+ / Page+
L/R	L/R	CH PAGE –	CH- / Page-
ANGLE	Angle	ANGLE / INFO	Info / Angle
ZOOM	Zoom	SIZE / ZOOM	Zoom / Size
RESUME	Resume	LIST / SMART	Smart / List

Original		Sustituto	
REMAIN	Remain	TOP MENU / D.MENU	D. Menu / Top