Original		Sustituto	
	On / Standby		Power
	Input Selector V		1
	Input Selector V		2
	Input Selector V		3
	Input Selector Multi CH		5
	Input Selector		6
	Input Selector		7
	Input Selector Tuner		8
	Input Selector C		9
	Dimmer		0
	Sleep		Sleep / Timer
	Guide/Top		Menu / Home
	Muting		Mute / Dimmer
	Return		Back / Return
	Setup		Eject / Surround
	Enter		OK
	Up		Up

Original		Sustituto	
	Down		Down
	Right		Right
	Left		Left
	Play		Play / Slow
	Rev. Play		Pause / Step / Freeze
	Stop		Stop / Hold
	<<		>> / Tune+
	>>		I<< / Preset-
	I<<		<< / Tune-
	>>I		>>I / Preset+
	Listening Mode Stereo		Red / Netflix / Search
	Listening Mode Surround		Green / APP / Repeat
	Listening Mode <		Yellow / YouTube / Repeat
	Listening Mode >		Blue / Prime Video / Random
	Test Tone/Audi		Audio / Lang I/II
	CH Sel/Subtitl		Subtitle / EQ
	Level -/Random		TV/Radio / Program

Original		Sustituto	
REPEAT LEVEL+	Level +/ Repeat	SIZE ZOOM	Zoom / Size
DISPLAY	Display	ANGLE INFO	Info / Angle
L.NIGHT DVD	L. Night	LIST SMART	Smart / List
CINE FLTR HDD	Cine FLTR	MEDIA DISPLAY	Display / Media
INPUT	Input Tv	SHIFT + RDS AV INPUT	Shift + AV / Input / RDS
CH DISC ALBUM +	CH/Disc/Album	CH PAGE +	CH+ / Page+
CH DISC ALBUM -	CH/Disc/Album-	CH PAGE -	CH- / Page-
VOL +	Vol +	VOL +	Vol +
VOL -	Vol -	VOL -	Vol -
Power	Power Tv/ Standby	SHIFT +	Shift + Power
VOL +	Vol + Tv	SHIFT + VOL +	Shift + Vol +
VOL -	Vol - Tv	SHIFT + VOL -	Shift + Vol -
1 V1	1 Tv	SHIFT + TV 1	Shift + 1
2 V2	2 Tv	SHIFT + DVD 2	Shift + 2
3 V3	3 Tv	SHIFT + CD-STB 3	Shift + 3
4 V4	4 Tv	SHIFT + VIDEO 4	Shift + 4
5 MULTI CH	5 Tv	SHIFT + TAPE 5	Shift + 5

Original		Sustituto	
6 DVD	6 Tv	SHIFT + TUNER 6	Shift + 6
7 TAPE	7 Tv	SHIFT + AUX-HDD 7	Shift + 7
8 TUNER	8 Tv	SHIFT + USB 8	Shift + 8
9 CD	9 Tv	SHIFT + BLUETOOTH 9	Shift + 9
0 DIMMER	0 Tv	SHIFT + HDMI-SAT 0	Shift + 0
+10	+10 Tv	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--
PREVIOUS MENU MUTING	Muting/ Previous Menu Tv	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer
ENTER	Enter Tv	SHIFT + OK	Shift + OK
PLAYLIST/CAT+	Right Tv	SHIFT +	Shift + Right
PLAYLIST/CAT-	Left Tv	SHIFT +	Shift + Left
SETUP	Setup Tv	TOP MENU D.MENU	D. Menu / Top
	Up Tv	SHIFT +	Shift + Up
	Down Tv	SHIFT +	Shift + Down

Original		Sustituto		Original		Sustituto	
ON/STANDBY	Power		Power	PREVIOUS MENU MUTING	Previous Menu/Muting	DIMMER MUTE	Mute / Dimmer
1 V1	1	TV 1	1	PLAYLIST/CAT	Left/Playlist/Ca		Left
2 V2	2	DVD 2	2	ENTER	Enter	OK	OK
3 V3	3	CD-STB 3	3	PLAYLIST/CAT	Right/Playlist/C		Right
4 V4	4	VIDEO 4	4	RETURN	Return	RETURN BACK	Back / Return
5 MULTI CH	5	TAPE 5	5		Down		Down
6 DVD	6	TUNER 6	6	SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
7 TAPE	7	AUX-HDD 7	7		Pause	STEP-FREEZE	Pause / Step / Freeze
8 TUNER	8	USB 8	8		Play	SLOW	Play / Slow
9 CD	9	BLUETOOTH 9	9		Stop	HOLD	Stop / Hold
VCR	VCR	SHIFT + VIDEO 4	Shift + 4		<<	TUNE-	<< / Tune-
+10 10	+10/10/-/--	GUIDE EPG	Guide / EPG / -/--		>>	TUNE+	>> / Tune+
0 11 DIMMER	0/11	HDMI-SAT 0	0		I<<	PRESET-	I<< / Preset-
CLR 12 SLEEP	CLR	CLEAR EXIT CANCEL	Exit / Cancel / Clear		>>I	PRESET+	>>I / Preset+
GUIDE TOP MENU	Top Menu	TOP MENU D.MENU	D.Menu / Top	STEREO	Stereo	TITLE SOUND	Sound / Title
	Up		Up	SURROUND	Surround	SURROUND	Eject / Surround
PREVIOUS MENU MUTING	Previous Menu/Muting	HOME MENU	Menu / Home		< Listening Mode	SHIFT + PRESET-	Shift + I<< / Preset-

Original		Sustituto		Original	Sustituto
	Listening Mode >	SHIFT + PRESET+	Shift + >>I / Preset+		
AUDIO TEST TONE	Audio	LANG I/II AUDIO	Audio / Lang I/II		
SUBTITLE CH SEL	Subtitle	EQ SUBTITLE	Subtitle / EQ		
RANDOM LEVEL-	Random	Prime Video RANDOM	Blue / Prime Video / Random		
REPEAT LEVEL+	Repeat	APP REPEAT	Green / APP / Repeat		
DISPLAY	Display	MEDIA DISPLAY	Display / Media		
PLAY MODE VCR	Play Mode VCR	FORMAT PICTURE	Picture / Format		
L NIGHT DVD	DVD	SHIFT + DVD 2	Shift + 2		
CINE FLTR HDD	HDD	SHIFT + AUX - HDD 7	Shift + 7		

Original		Sustituto	
	On / Standby		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	+10/10/-/--		Guide / EPG / -/--
	0/11		0
	12		Fav / Marker / PC
	Disc+		CH+ / Page+
	Vol +		Vol +
	Disc-		CH- / Page-
	Vol -		Vol -

Original		Sustituto	
	Pause		Pause / Step / Freeze
	Play		Play / Slow
	Stop		Stop / Hold
	<<		<< / Tune-
	>>		>> / Tune+
	I<<		I<< / Preset-
	>>I		>>I / Preset+
	Stereo		Audio / Lang I/II
	Surround		Eject / Surround
	< Listening Mode		Shift + I<< / Preset-
	Listening Mode >		Shift + >>I / Preset+
	Random		Blue / Prime Video / Random
	Repeat		Green / APP / Repeat
	Display		Display / Media

Original		Sustituto	
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	+10/ 10/ -/ --		Guide / EPG / -/--
	0/ 11		0
	CH+		CH+ / Page+
	CH-		CH- / Page-
	Pause		Pause / Step / Freeze
	Play		Play / Slow
	Stop		Stop / Hold

Original		Sustituto	
	<<		<< / Tune-
	Stereo		Audio / Lang I/II
	Surround		Eject / Surround
	< Listening Mode	SHIFT +	Shift + I<< / Preset-
	Listening Mode >	SHIFT +	Shift + >>I / Preset+
	Play Mode		D.Menu / Top
	L.Night		Sleep / Timer